

3. Press the front of the sunroof switch and hold for 30 seconds.
4. After 30 seconds the sunroof will begin to move. Keep the front of the switch pressed until the sunroof has fully opened, then closed.
5. Once the open/close cycle has completed and the sunroof has stopped moving, release the switch.

The sunroof can now be operated as normal.

## WINDOW RESET

The windows will need to be reset if the battery is disconnected, becomes discharged or power supply is interrupted.

Once the power supply is restored, reset the windows as follows:

1. Close the window fully.
2. Release the switch, then lift it to the close position and hold for 2 seconds.
3. Open the window fully.
4. Release the switch, then push it to the open position and hold for 2 seconds.
5. Lift and release the switch to operate the one-touch function.
6. Repeat the procedure on each window.

## WARNING TRIANGLE

The warning triangle is located in the luggage compartment, attached to an anchor point.

## FIRST AID KIT

If supplied, the first aid kit is strapped to the side of the luggage compartment.

## FIRE EXTINGUISHER

If supplied, the fire extinguisher will be located either in the luggage compartment, or mounted to the front passenger seat.

## REPAIRING MINOR PAINT DAMAGE

Regularly inspect the paintwork for damage. Any stone chips, fractures, or deep scratches, in the paint/bodywork should be repaired promptly. Bare metal will corrode quickly and if left untreated can result in expensive repairs.

## CLEANING THE ALLOY WHEELS



Only use approved wheel cleaning products.

## CLEANING THE EXTERIOR



Never use cleaning products which are not approved for use on vehicles.



Some high pressure cleaning systems are sufficiently powerful to penetrate door and window seals and will damage trim and door locks. Never aim the water jet directly at the engine air intake, heater air intakes, body seals or at any components which may be damaged.

Do not aim the water jet directly at any rubber gaiters or seals on suspension joints.

Ensure that the water jet nozzle is more than 300mm (11.8 in) away from vehicle components.



Following cleaning of the vehicle exterior (particularly with a pressure washer), it is recommended that the vehicle is taken for a short drive in order to dry out the brakes.

## WASHING THE VEHICLE PAINTWORK



Substances which are corrosive can damage the vehicle's paintwork and should be removed to prevent damage.