


# Wipers and washers

## WIPER OPERATION



E132404

1. Rotate control to adjust sensitivity.

**MAX:** Maximum sensitivity.

**MIN:** Minimum sensitivity.

2. Fast speed wipe.
3. Normal speed wipe.
4. Rain sensor activated wipe.
5. Windscreen washer button.
6. Single wipe.

❗ Do not operate the windscreen wipers on a dry screen.

❗ In freezing or very hot conditions, ensure that the wipers have not stuck to the windscreen before operating.

❗ Remove any snow, ice or frost from the windscreen, around the wiper arms and blades, and the screen scuttle, before operating the wipers.

**Note:** If the wiper blades become stuck or jammed, an electronic cut-out may temporarily halt wiper operation. If this happens, switch off the wipers and the ignition. Clear any

obstructions and free the wiper blades, before attempting to switch on the ignition.

## SPEED-DEPENDENT MODE

If vehicle speed drops below 2 km/h (1.2 mph) with the wipers operating, the wipers will switch to the next lowest speed. When vehicle speed increases to over 8 km/h (5 mph), the original wiper speed settings are restored.

## RAIN SENSOR

❗ Ensure that the wipers are switched off before entering a car wash. If the rain sensitive wipers operate during the car washing process damage may occur to the wiper mechanism.

The rain sensor is able to detect the presence and amount of rain, dirt or snow on the windscreen and automatically activates the windscreen wipers accordingly. Static droplets may not be detected on initial start-up, use a single wipe to clear the screen.

To activate the rain sensitive wipers, move the wiper stalk to the rain sensor position and