


## VIDEO MEDIA PLAYER CONTROLS



E151162

1. Touch **TV/My video** to display the **Source** soft key. Touch to view and select **DVD** or other forms of video media (**CD/USB**), provided the relevant media is present. The selected option will be displayed.  
*Note: After 5 seconds without use, the TV/My video menu will close.*
2. Preview screen for video media information: Touch to select full screen mode. Short touch the screen again to view the controls at any time. To return to preview mode, touch and hold the full screen view.
3. **Settings:** Depending on the video media specification, there are 3 sub-menus within the settings: **Options**, **VOD** (Video On Demand), and **Audio settings**. **VOD** allows playing of DivX VOD content from a video media. The 8 digit registration code will be displayed when the VOD soft key is touched. The player must also be registered with DivX. See **99, LICENSING**.
4. **Tools:** The following options can be selected:
  - **GOTO:** The GOTO menu allows you to access specific parts of the video, by **Chapter** or **Title number**.
  - Subtitles.
  - Angle.
  - Audio.
  - Top menu.
5. **Menu:** Select to view the Video media menu. On some screens this may be replaced by a **Browse** soft key.
6. **Seek up:** Select to view the next DVD chapter or the next chapter of the video media.
7. **Seek up:** Select to pre-stop playback. A second touch will stop and reset the DVD.
8. **Play/Pause:** Select to start/restart play.
9. **Seek down:** Select to view the previous DVD chapter or the previous chapter of the video media.

# Video media player

For information on the CD/DVD loading slot and eject button, and the use of the audio/video controls on the audio unit and steering wheel, see **97, AUDIO/VIDEO CONTROLS**.

## **VIDEO MEDIA INHIBIT WITH VEHICLE MOVING**

When the vehicle is moving, the video picture will automatically be inhibited. The Touch screen will display the **TV/My video** screen and the relevant safety message will be displayed.

## **FULL SCREEN VIEW**

When full screen mode is selected, the seek controls operate in the same manner as they do in preview mode.

Use the relevant soft key to select the **4:3**, **16:9**, or **Zoom** option, to magnify the picture.