

WARNING LAMPS AND INDICATORS

RED warning lamps are for primary warnings. A primary warning must be investigated immediately, seek qualified assistance if necessary.

AMBER and YELLOW warning lamps are for secondary warnings. Some indicate that a vehicle's system is in operation, others indicate that the driver must take action and then seek qualified assistance as soon as possible.

Other warning lamps within the Instrument panel indicate system status, such as blue for main beam and green for direction indicators, when in operation.

LAMP CHECK

A warning lamp bulb check is initiated when the ignition system is switched on and lasts for 3 seconds (except for the airbag warning lamp which will remain on for 6 seconds). If any warning lamp remains on after this period, investigate the cause before driving.

Some warning lamps have associated messages displayed on the Message centre.

Note: *Not all warning lamps are included in the check (e.g., high beam headlamps and direction indicators).*

CRITICAL WARNING MESSAGE (RED)



Illuminates when a critical warning message is available in the Message centre.

GENERAL WARNING/INFORMATION MESSAGE (AMBER)



Illuminates when a non-critical warning message or an information message is available in the Message centre.

BRAKE (RED)



Do not drive if the message LOW BRAKE FLUID is displayed. Check the brake fluid level and top up, as necessary. If necessary, seek qualified assistance before continuing.



Illuminates when the ignition is on and the Electric parking brake (EPB) is applied, and/or the brake fluid is low.

The warning lamp will also illuminate when there is a fault with the Electronic brakeforce distribution (EBD) system.

If the warning lamp is on and there are no associated messages, it means that the EPB is on.

If the warning lamp is illuminated and the message **PARK BRAKE ON** is displayed, it means that the EPB is applied, but the vehicle is moving. Release the EPB, or stop the vehicle when it is safe to do so.

If the lamp is illuminated and the message **LOW BRAKE FLUID** is displayed, loss of braking in one or both brake circuits may be imminent. Stop the vehicle gently and check and top up the brake fluid reservoir, using the recommended fluid. If the warning message remains, do not drive the vehicle until the brake fault is rectified. Seek qualified assistance before continuing.

If the lamp illuminates and the message **EBD FAULT** is displayed in the Message centre, a fault with the EBD system is indicated. The braking system will still function, but without EBD assistance.

Have the fault rectified by your Dealer/ Authorised Repairer.