

The rain sensor is able to detect the presence and amount of rain, dirt, or snow on the windshield and automatically activates the windshield wipers accordingly. Static droplets may not be detected on initial start-up, use a single wipe to clear the screen.

To activate the rain sensitive wipers, move the wiper control to the rain sensor position and adjust the rain sensor sensitivity control, as required. When the rain sensitive wipers are activated and when sensitivity is increased, a single wipe will operate.

## WINDSHIELD WASHERS

### WARNING

**Some windshield wash products are flammable; do not allow windshield wash to come into contact with sources of ignition.**

### **NOTICE**

*Only windshield wash products which are approved for automotive use should be used, and then only in accordance with the manufacturer's instructions.*

To operate the wash/wipe, press and release the button on the end of the wiper control. The wipers will perform 5 normal speed wipes, followed by a drip wipe (if configured). The washers will operate during the first 2 wipes.

If the washers are operated with the wipers operating at normal or fast speed, the washer jets will operate for 2 wipes and operation of the wipers will not be affected.

**Note:** *If the button is pressed and held, the wipers and washers will operate at normal speed until the button is released (or for a maximum of 10 seconds).*

*After the button is released, the wipers will operate for a further 3 wipes, followed by a drip wipe (if configured).*

## TIMED JET FUNCTION

If the Timed jet function is configured, the washer jets will only operate on the up stroke of the wipers.



This function can be enabled/disabled by your Dealer/Authorized Repairer.

## DRIP WIPE

If the Drip wipe function is configured, the wipers will operate 4 seconds after a wash/wipe cycle has finished, to clear any remaining drips from the windshield.



This function can be enabled/disabled by your Dealer/Authorized Repairer.

## HEADLAMP WASHERS

Headlamp power wash operates automatically with the windshield wash, and will only operate if the headlamps are switched on and there is sufficient washer fluid in the reservoir.

Headlamp wash operates with every fourth operation of the windshield washers, provided that 10 minutes have elapsed since the last operation of the headlamp washers.

**Note:** *The power wash sequence is reset when the headlamps or the ignition are turned off.*

**Note:** *Headlamp power wash is inhibited when the low washer fluid warning is on.*