USING SNOW CHAINS

It is essential that only snow chains of the recommended type are fitted.

Do not fit snow chains to 20 inch tyres.

Snow chains can only be fitted to rear wheels. They should not be used on temporary use spare wheels.

Contact your Dealer/Authorised Repairer for details and availability of approved snow chains.

The maximum speed when using snow chains is 50 km/h (30 mph).

Note: *When using snow chains, select JaguarDrive Control Winter mode* ***and*** *switch DSC off. DSC would reduce the deep snow traction capability as it would limit wheel spin to a level below that which is required to generate maximum traction.*