PORTABLE MEDIA CONTROLS



The following portable devices can be used on the Media system: **iPod**, **USB**, **AUX**, and **Bluetooth**® wireless technology devices.

Note: *Auxiliary devices have no Touch screen controls.*

1. **Track list**: Touch to select the list of tracks from the connected device.
2. **Browse**: Touch to select the menu screen for the required music or audio source subject list for the connected device: **Playlists**, **Artists**, **Albums**, **Songs**, etc.
3. **Source**: Touch to select the media source menu screen.

   Note: *The media source has to be connected to the vehicle before it will appear in the media source list.*
4. Status icons: When a phone is connected, the battery level and network signal strength is displayed. Also, when selected, **TA** (Traffic announcements) is displayed.
5. Information relating to the music or audio being played.
6. Image display:
   - If available, the album art for the current track being played will be displayed.
   - When a video (from a connected USB source only) is about to be played, an image from the video is displayed.
7. Progress bar: Drag the spot or touch the line to move forwards or backwards through the track.
8. Touch to select the **SETTINGS** pop-up menu. Select **Media** or **Bluetooth**, via the **Settings** option.