trailer sway....91
weights....90
Towing eyes
front....256
rear....257
tracDSC
stability control....111
Tracking your vehicle
InControl secure....173
Traction control
switching between DSC and tracDSC....111
switching off....111
switching on....112
tracDSC....111
Traffic sign recognition....131
Trailer
electrical connections....95
sway....91
towing weights....90
Trailer direction indicators warning lamp....55
Trailer tow assist....91
Training
videos 9,56,79,145,152,156,161,164,171,174,180–182,189
Transmission
automatic....107
gear shift warning lamp....54
limp home mode....109
manual....109
Transmitters
smart key....268
Transporting the vehicle....256
Trip computer....48
average speed....48
fuel consumption....48
fuel range....49
reset....48
trip distance....49
Turning ACC follow mode off....55
Tyre pressure checking after a repair....248
Tyre pressure monitoring system (TPMS)..243
tyre care....237
valves....239
warning lamp....54
Tyre pressures....244
Tyre repair kit
checking pressures....248
repair procedure....247
safety information....246
using....247
Tyres
age degradation....240
changing....244
flat spots....240
important information....255
Indian regulations....242
pressure check....243
pressures....238
recommended tyre pressure look-up....244
repair kit....246
repair kit use....247
repair procedure....247
replacements....239
snow chains....241
speed ratings....237
temporary use spare....244
TPMS....243
warning lamp....54
tyre care....237
tyre repair safety....246
tyre wall markings....236
use of spare tyre....255
valves....239
vehicle loading....244
wall markings....236
winter....240

U

Under bonnet covers....199–200
Understeer....111
Unlocking....18
all doors....6
driver's door....6
entry and exit mode....29
global opening....6, 8
keyless entry....9
luggage compartment....10
mode....6
multi point entry....6, 8