- **Auto Sensitivity**: The air quality sensor, for Automatic recirculation, can be set to **Low**, **Medium** or **High**. Select **Off** to disable Automatic recirculation.
- **Auto Power**: The blower speed for automatic operation can be set to **Low**, **Medium** or **High**.
- **Auto heated screens**: The automatic operation of the front and/or the rear heated screens can be enabled/disabled.

***Note:*** *Selection of the* ***ECO*** *driving mode may automatically alter some status and settings for these menus (dependent on previous selections). See* ***144, ECO****.*

## AUTOMATIC RECIRCULATION

If an air quality sensor is fitted, the Climate control system will monitor exterior air pollution and select recirculation if it reaches a predetermined level. This feature only operates when selected from the **CLIMATE SETTINGS** menu. Recirculation sensitivity can also be changed in the **CLIMATE SETTINGS** menu. See **80, AIR QUALITY SENSOR**.

Pressing the recirculation button will not deactivate automatic recirculation.

## AIR QUALITY SENSOR

The sensitivity of the air quality sensor can be adjusted using the Touch screen:

1. Select **GENERAL SETTINGS** from the **FRONT CLIMATE** menu, followed by **Climate**, to view the **CLIMATE SETTINGS** screen.
2. Touch the buttons on the screen to increase/decrease sensitivity.
   To switch off air quality sensing, touch **Off**.

## HEATED SEATS

***Note:*** *Seat heaters consume a large amount of battery power. They will only operate when the engine is running.*

***Note:*** *If fitted, the rear Heated seats (non-climate) can only be operated by pressing the buttons located at the rear of the centre console.*

Press the relevant rear Heated seat button, to switch the required seat heater on at the maximum setting. The 3 LED indicators on the button will illuminate.

Press a second time to set the Heated seat at the medium setting; 2 LED indicators will illuminate.

Press a third time to set the Heated seat at the lowest setting; 1 LED indicator will illuminate.

Press a fourth time to switch off.

## CLIMATE SEATS

***Note:*** *The Heated/Climate seats will only operate when the engine is running.*

Touch the **Front seats** soft key from the **FRONT CLIMATE** menu, or press the Heated/Climate seat button.

***Note:*** *The* ***Front seats*** *menu will be displayed.*

***Note:*** *A seat icon, at the top of the Touch screen, will change colour to indicate the status of the Climate seats; red for heated operation and blue for cooled operation.*

**Heated ventilation**

- Touch the up arrow icon to switch heated ventilation on at the maximum setting (3 red bars).
- Touch the down arrow icon once or twice to reduce the ventilation setting (2 and 1 red bars).
- Touch the down arrow a third time to switch off heated seat ventilation.