PAIRING YOUR PHONE

Before use, your mobile phone must be connected or paired with the vehicle's Bluetooth system.

Vehicles with touch-screen

Follow these steps to pair your phone with the vehicle:

- Switch the vehicle's ignition ON (position II).
- Press the button, to the left of the touch-screen.
- Using the touch-screen keypad, enter the code ##3#*#, then touch .
- The message Discover Me will be displayed, to confirm that the system is ready to pair with a mobile phone.
- Switch on your mobile phone's Bluetooth connection, using the phone's menu. (See your phone's manual for more information.)
- Select 'search for other Bluetooth devices' or 'Audio Accessories' from your mobile phone's menu.
- Select 'Jaguar' in your phone's paired device list, in order to connect to the vehicle's Bluetooth system.
- Enter the Passkey on your mobile phone (the Passkey is 1313).
- Under certain circumstances, the message No BT Phone may be displayed briefly.
- After a short delay, the message
 Phone Connected will confirm that the phone and vehicle are paired.

Note:

- Once a mobile phone has been paired with the vehicle, the system will look for the same phone each time the ignition is switched ON. If no phone is detected, the message No BT Phone will appear on the touch-screen to confirm that no phone is connected after approximately 3 minutes.
- When a mobile phone is paired to the vehicle and the Bluetooth connection is established, one bar will be displayed next to the antenna icon. However, you will need to refer to your mobile phone's display to determine the strength of the network signal.
- If an incorrect Passkey is entered, your mobile phone should prompt you to enter the correct Passkey.
- If there is a delay of approximately
 5 minutes when pairing a phone with
 the vehicle, a screen with the message
 Handset In Use may be displayed. If
 this occurs, switch the vehicle ignition
 to OFF and wait for at least 5 minutes
 before repeating the pairing
 procedure.

Vehicles without touch-screen

Follow these steps to pair your phone with the vehicle:

- Switch the vehicle's ignition ON (position II).
- Press the button on the audio panel. **SIG** will be displayed.
- Using the audio panel keypad, enter the code ##3#*# and press the button.

It is recommended to use the code ##3#*# to pair your phone because this code has no automatic time-out period.

- SIG**** will be displayed.
- Switch on your mobile phone's Bluetooth connection, using the phone's menu. (Refer to the manual for of your specific phone.)
- Select 'search for other Bluetooth devices' or 'Audio Accessories' from your mobile phone's menu.
- Select 'Jaguar' in your phone's paired device list, in order to connect to the vehicle's Bluetooth system.
- Enter the Passkey on your mobile phone (the Passkey is 1313). SIG will be displayed initially.
- Once the vehicle and phone are paired, SIG* will appear on the audio panel.

Once a mobile phone is paired with the vehicle, **SIG** will be displayed initially when the ignition is switched ON. **SIG*** will then be displayed, once the phone is detected.

If the phone is not detected within 2 minutes (after switching ON the ignition), the audio system will exit Phone Mode and revert to its previous audio mode.

Note:

- Once a mobile phone is paired with the vehicle, SIG***** will be displayed initially when the ignition is switched ON. If no phone is detected, the message SIG will confirm that no phone is connected after approximately 2 minutes.
- If an incorrect Passkey is entered, your mobile phone should prompt you to enter the correct Passkey.

All vehicles

Once a mobile phone is paired with the vehicle, the vehicle will look for this specific phone every time the ignition is switched ON.

Pairing other phones

Only one mobile phone can be paired with the vehicle at a time. Once paired, the vehicle will look for the same phone each time the ignition is switched ON (position II): you do not need to manually pair the phone with the vehicle every time you switch the ignition ON.

The Bluetooth function of your mobile phone must be switched on when the ignition is switched ON in order for it to pair with the vehicle automatically.

If a different Bluetooth mobile phone is to be used with the vehicle, it must be paired manually, as described previously. This phone will then become the default phone, which the system will look for each time the ignition is switched ON.

Disconnecting (unpair) a phone

To disconnect a mobile phone from the system:

- Press the button on the audio panel or touch-screen.
- Enter ##3#*# on the keypad, and press the button.

A mobile phone can also be disconnected via the mobile phone's keypad. Refer to your phone's manual for more details.

REJECTING A CALL

(The XJ, X-TYPE and S-TYPE)



Press **CANCEL** on the audio panel to reject an incoming call.

(The XK only)



Press **C/TA** on the audio panel to reject an incoming call.

LAST NUMBER REDIAL

(The XK only)



Press and hold the Send/End button on the audio panel to recall the last number dialled. See page 37 for more information.

RECONNECTING A PHONE

Once a mobile phone has been paired with the vehicle, Jaguar may be shown in the phone's list of Bluetooth devices (see your mobile phone manual for more information).

If you manually unpair the phone, it is advisable to delete Jaguar from the list of Bluetooth devices before pairing it with the vehicle again.

EXITING THE VEHICLE

The vehicle telephone system will remain active for 6 minutes after the ignition is switched OFF. If a call is received during this period, and the mobile phone remains within 10 metres (33 feet) of the vehicle, the call will still be transferred to the vehicle system: you will not be able to hear the call through the phone.

There are two ways of allowing a call to be taken via the phone:

- Transfer the audio function back to the mobile phone.
- Switch off the Bluetooth connection via the mobile phone (phone will remain paired).

Refer to your mobile phone manual for more information.

SILENT MODE

Certain mobile phones have a Silent mode or profile, which prevents the handset from ringing when a call is received

If the mobile phone is set to Silent, it will also prevent the vehicle phone system from ringing.