


AIRBAGS AND ACTIVE HEAD RESTRAINTS



E144238

1. Airbag warning information is printed on the driver and passenger sun visors.
2. Airbag deactivation indicator. When this is illuminated, the front passenger airbag will not be deployed in the event of an impact.

Note: The indicator will illuminate for approximately 6 seconds as a bulb check when the ignition is switched on.

3. Both front seats are equipped with Active Head Restraints (AHR), which reduce the risk of neck and spinal injury (whiplash) in the event of a rear impact, by moving the head restraint upwards and forwards, supporting the occupant's head.
After activation, the whiplash protection mechanism resets automatically and does not need to be replaced.
4. The curtain airbags may deflate at a slower rate than the front or side airbags, to afford prolonged protection.