


Navigation system

USING THE NAVIGATION SYSTEM



E 143957

From the **Home menu** touch the **Navigation** soft key (1). Alternatively, press the **NAV** shortcut button on the fascia (2). A **CAUTION** screen will be displayed.

If the navigation screen language has not been set, select **Language**, and touch **OK** to confirm. The **CAUTION** screen will return.

After touching **Agree**, the touch screen will display the previously displayed map view. This will show the current vehicle position. Touch the **Nav menu** soft key to display the main menu screen.

At this point, the first time user should set up personal preferences in the **Nav set-up** area. These settings are applied whenever navigation is used.

For a short-cut to set a destination, press **Destination entry** (3). The Destination entry menu will be displayed after pressing **Agree** on the **CAUTION** screen.