PAIRING AND CONNECTING USING THE MEDIA PLAYER

For further information on Bluetooth®, see 123. BLUETOOTH® INFORMATION.

Note: The process of pairing and connecting your media device with the vehicle, using the media device, will vary depending on the type of media device.

- 1. Switch on the ignition and ensure the touch screen is active.
- 2. From the Home menu, select **Audio/Video**, then **Mv music**.
- 3. A menu will appear. Select Search new.
- 4. Select Device to vehicle option.

Note: The vehicle's Bluetooth® system is only discoverable for 3 minutes.

- 5. Using the media device, search for Bluetooth® devices. On some media devices, this is referred to as new paired device. See your media device's operating instructions for further information.
- 6. When the vehicle's Bluetooth® system is discovered, follow the on-screen instructions. Select Yes when prompted, to confirm the pairing.
 - Either your device or the vehicle system will ask for a PIN (Personal Identification Number). When prompted, enter a PIN of your choice and select **OK** to confirm.
- 7. Enter the same PIN into the other device.
- Once your device is paired and connected to the system, a confirmation message will be displayed, before switching to the My music, Bluetooth® screen.

Note: Some media devices do not automatically connect and need to be manually connected, via the device or by using the **Change device** option.

PAIRING AND CONNECTING USING THE TOUCH SCREEN

For further information on Bluetooth®, see 123. BLUETOOTH® INFORMATION.

- Switch on your device's Bluetooth® connection. Make sure that it is in Bluetooth® discoverable mode, sometimes referred to as find me mode (see your device's operating instructions for more information).
- 2. Switch on the ignition and ensure the touch screen is active
- 3. From the Home menu, select Audio/Video, then Mv Music.
- 4. A menu will appear. Select Search new.
- 5. Select Vehicle to device option.
- Identify your device from the displayed list and select the corresponding Pair and connect option.

Note: If more than 5 devices are detected, it may be necessary to use the scroll bar to see the entire list.

- 7. When prompted, enter the PIN (Personal Identification Number) code into your device. See your device's operating instructions for more information.
- 8. Once your device is paired and connected to the system, a confirmation message will be displayed before switching to the My music. Bluetooth® view.

Note: Due to the duration of a Bluetooth® search, it is advised that the time-out to home screen feature is switched off before attempting to search for Bluetooth® devices. This setting can be changed within Set-up, Screen, Time out home.