Portable media

LOSS OF CONNECTION

If a loss of connection between the vehicle and the Bluetooth® device occurs, a pop-up is displayed. Select **Reconnect** to automatically restore the connection. A confirmation pop-up will appear before the touch screen reverts to its previous mode.

CHANGING/DISCONNECTING A DEVICE

- 1. From the playback control menu, select **Settings**.
- 2. From the Settings menu, select Register.
- Select Disconnect. A confirmation pop-up will appear and then you will be given the option to Search new or select a different device from the list of paired devices.