
Storage compartments

STORAGE COMPARTMENTS



- 1. Cubby box.
- 2. Cup holders.



Do not drink, or use the drinks holders when driving.

Note: When Valet mode is selected the glove box release is disabled.

3. Glove box. Open using the glove box release (arrowed).

Note: When Valet mode is selected the glove box release is disabled.

- 4. Rear armrest cubby box.
- 5. Front door stowage.
- 6. Rear door stowage.
- 7. Auxiliary power socket.

