

---

About this handbook . . . . .	1-2	How the system works . . . . .	1-1
Additional guidance features . . . . .	4-4	Loading the map DVD . . . . .	1-5
– turns list . . . . .	4-4	Long-haul areas . . . . .	4-5
Control panel . . . . .	1-5	– destination setting . . . . .	4-6
Destination menu . . . . .	3-4	– long-haul area caution . . . . .	4-6
– address . . . . .	3-4	– long-haul cities . . . . .	4-8
– intersection . . . . .	3-4	– rest areas . . . . .	4-7
– local points . . . . .	3-6	– road coverage . . . . .	4-6
– map cursor . . . . .	3-5	– route guidance . . . . .	4-6
– memory points . . . . .	3-6	– selecting stored destinations . . . . .	4-7
– point of interest . . . . .	3-5	Main features of the system . . . . .	2-1
– recent destination points . . . . .	3-5	– avoid roads . . . . .	2-1
– way points . . . . .	3-6	– local points . . . . .	2-1
Getting started . . . . .	3-1	– memory points . . . . .	2-1
– initialisation . . . . .	3-1	– point of interest . . . . .	2-1
– map display . . . . .	3-2	– screen guidance . . . . .	2-1
– panel controls . . . . .	3-2	– using way points . . . . .	2-1
– POI icon display . . . . .	3-2	– voice guidance . . . . .	2-1
– road safety caution . . . . .	3-1	– way points . . . . .	2-1
		Main menu . . . . .	3-3
		Menu structure . . . . .	2-6

# Index

---

Option menu . . . . .	3-10	Safety information . . . . .	1-2
– edit memory points . . . . .	3-10	Screen displays . . . . .	1-6
– edit recent destination points . . . . .	3-10	– arrow view screens . . . . .	1-7
– edit way points . . . . .	3-11	– map screens . . . . .	1-6
– GPS information . . . . .	3-11	– menu screens . . . . .	1-9
– system information . . . . .	3-11	– screen symbols . . . . .	1-8
		– scrolling indicators . . . . .	1-9
Route calculation . . . . .	4-1	Screen guidance . . . . .	4-3
– calculation . . . . .	4-1	– arrow view . . . . .	4-3
– confirm destination . . . . .	4-1	– hybrid view . . . . .	4-3
– continue trip . . . . .	4-1	– map view . . . . .	4-3
Route guidance . . . . .	4-2	Setup menu . . . . .	3-7
– driving off . . . . .	4-2	– auto reroute . . . . .	3-8
– panel controls . . . . .	4-2	– calculation method . . . . .	3-8
Route menu . . . . .	3-12	– display colour . . . . .	3-7
– avoid roads . . . . .	3-12	– guide method . . . . .	3-8
– cancel current destination . . . . .	3-12	– language . . . . .	3-8
– change calculating method . . . . .	3-13	– map direction . . . . .	3-7
– skip way point . . . . .	3-13	– POI icon . . . . .	3-7
Route setting example . . . . .	2-2	– summer time . . . . .	3-9
		– time zone . . . . .	3-9
		– voice prompt . . . . .	3-8

Text input .....	1-12
Using the controls .....	1-10
– volume adjustment .....	1-11
Using the system .....	1-2
– city name lists .....	1-4
– clock .....	1-4
– errors in vehicle position .....	1-3
– estimated time to destination .....	1-4
– Jaguar dealership locations .....	1-4
– languages and distance units .....	1-4
– map DVDs .....	1-4
– reception of GPS signals .....	1-3
– road junction layouts .....	1-4
– route guidance precision .....	1-3
– screen cleaning .....	1-4





**JJM 10 05 14/30**