

## Frequently Used Functions

The starting position for all these functions is the map screen showing the current position of the vehicle. If any other screen is shown, push the **NAV** button to display the map screen.

### Getting Started

#### Entering a destination by address

**Nav Menu** → Destination Entry → Address → enter the address details required → **Dest.** → **Start.**

#### Entering a destination to a town centre

**Nav Menu** → Destination Entry → Address → enter the town name required → **Town Centre** (icon) → **Dest.** → **Start.**

#### Using a point of interest as a destination

**Nav Menu** → Destination Entry → Point of Interest → select the point required → **Dest.** → **Start.**

#### Storing a location as the home position

**Nav Menu** → Stored Locations → Home → **Add** → enter the address details required → **OK.**

#### Adding a memory point

**Nav Menu** → Stored Locations → Memory Point → **Add** → enter the address details required → **OK.**

## Options Available While Driving

### Setting a destination to the home position

Touch the screen → **Home.** (Only available when a home position is set.)

### Storing a map location as a memory point

Scroll the screen → **Store** → **OK.**

### Displaying point of interest icons

Touch the screen → **POI** → select a POI category.

### Changing the map heading (north up/heading up)

Touch the Map Orientation button.

**Note:** Heading up is not available if scale is greater than 4 km or 2 miles.

## Options Available Only With a Route Set

### Cancelling guidance

**Nav Menu** → Route Options → Cancel Guidance.

### Repeating voice guidance

Touch the **Repeat** button.

### Changing route preferences

Touch the screen → **Chg. Route** → Route Preferences → select the preferences required → **Calculate.**

# 13-2 Navigation System – Quick Reference

---

## Menu Structure

NAV → Nav Menu →

<b>Navigation Menu (page 7-1)</b>
Destination Entry
Route Options
Navigation Set Up
Display Options
Stored Locations

