

Bluetooth Operation

BLUETOOTH OPERATION

Bluetooth access code

The four digit access code required for Bluetooth 'Pairing' operation is 0000.

'Pairing' your phone to the vehicle

If your mobile phone supports this wireless feature, it will need to be 'Paired' to the vehicle. The 'Pairing' process will also be described in your mobile phone instructions.

1. With the vehicle ignition on, select the Bluetooth feature on your mobile phone.
2. Start the 'Search' function on your mobile phone.

Note: *This search process may vary from one handset/manufacture to another. Consult your mobile phone instructions for further details.*

Note: *Typically, when searching for other wireless devices the search range is 10 metres or less.*

3. The text 'Ford Audio' will appear on your mobile phone device list. This should be selected.

Note: *'Ford Audio' can be personalised by the user (e.g. The vehicle registration number).*

4. Your mobile phone display will now prompt you for the Bluetooth access code. Press the numeric keys 0000 on your phone.
5. When the code is accepted, the system will allow you to use the Bluetooth mode.

General Notes

- A maximum of 4 mobile phones can be 'Paired' to the vehicle.
- If more than one 'Paired' Bluetooth phone is in range, then the system will automatically select the last phone used in Bluetooth mode (If present).
- Priority can be given to other phones by de-selecting Bluetooth mode on the currently selected mobile phone.
- The last method of connection to the system (Bluetooth or via the cradle) will always take priority next time the system is used.