# Voice Control System

## GENERAL COMMANDS

***Note:*** *The voice control commands you should give are shown inside double pointed brackets* **>>...<<** *and the responses by the voice recognition system in single pointed brackets* **>...<**.

**Activating the user help function**

The commands
**>>Phone<<**
**>>Help<<**
calls up a list of telephone commands in spoken form.

**Command not recognised**

If a command is not recognised by the speech recognition system, it responds with
**>Sorry<**.

Please say your command again.

**Command list**

| User command | System response |
|---|---|
| Phone | Phone |
| Help | *(Reads out the telephone commands)* |