Locks


VALET MODE

Valet mode allows the vehicle to be locked by a parking attendant, without giving access to the luggage compartment and glove compartment.

Valet mode also prevents operation of the touch-screen, to prevent access to telephone numbers and navigation addresses.

Selecting valet mode

From the touch-screen Home menu, select **Valet**:



Enter your personally chosen, four-digit Personal Identification Number (PIN), using the keypad on the touch-screen. Select **OK**.

If you want to cancel the PIN or if an incorrect number is entered, touch the **C** button at any time while entering the number.

Once the PIN has been entered, a pop-up screen is displayed, advising you to remove the emergency key blade from the Jaguar Smart Key and to keep it safe. Select **OK**. The screen will indicate that the PIN has been accepted by displaying **Valet on**.

The luggage and glove compartments are now securely locked in Valet mode. On exiting and securing the vehicle, hand the Jaguar Smart Key, with the emergency key blade removed, to the attendant.

Note: Ensure that the emergency key blade is kept safely at all times.

Deselecting valet mode

When entry into the vehicle has been gained, the Valet mode screen will be displayed automatically. Enter your four-digit PIN and select **OK**.

A pop-up screen is displayed, advising you to return the emergency key blade to the Jaguar Smart Key. Select **OK**; the screen will indicate that your PIN has been accepted by displaying **Valet off**.

- The luggage compartment will return to the previously set security status.
- The glove compartment can now be opened as normal.

Note: If the PIN number has been forgotten, the luggage compartment can be unlocked using the emergency key blade. This will also cancel Valet mode.