



XK

OWNER'S HANDBOOK

Publication Part No. **JJM 10 02 30 121**

About this handbook

This handbook forms part of the Owner literature supplied with your new vehicle. Left-hand drive and right-hand drive conditions may be shown in the graphics and where information is specific to a particular country, it is indicated as such.

Please take the time to study the operating instructions with your vehicle as soon as you can.

IMPORTANT

The information contained in this handbook covers all vehicle derivatives and optional equipment. Some of the options may not be fitted to your vehicle, unless they formed part of the original vehicle specification. Therefore, some parts of this handbook may not apply to your vehicle. Furthermore, due to printing cycles, it may include descriptions of options before they become generally available.

The options, hardware and software in your vehicle are from the available specifications for the market in which the vehicle was intended for sale. If your vehicle is to be used in another geographical area, you may have to modify the vehicle specification to suit local conditions. Jaguar Cars Limited is not responsible for the cost of any modifications.

The information contained in this publication was correct when it went to print. Vehicle design changes may have been made after this handbook was printed. When this occurs a handbook supplement is added to the literature pack. Subsequent updates can be viewed on the Jaguar Internet site at: **<http://www.ownerinfo.jaguar.com>**.

In the interest of development, the right is reserved to change specifications, design or equipment at any time without notice and without incurring any obligations. This publication, or part thereof, may not be reproduced nor translated without our approval. Errors and omissions excepted.

Jaguar Cars Limited 2011.

All rights reserved.

Published by **Jaguar Cars Limited**.

Introduction

SYMBOLS GLOSSARY	9
LABEL LOCATIONS	9
FACIA AND CONTROLS	10
HEALTH AND SAFETY	12
DATA RECORDING	12
DISABILITY MODIFICATIONS	12
PARTS AND ACCESSORIES	13

Keys and remote controls

PRINCIPLE OF OPERATION	15
GENERAL INFORMATION ON RADIO FREQUENCIES	15
USING THE JAGUAR SMART KEY	16
UNLOCKING AND DISARMING THE VEHICLE	17
LOCKING AND ARMING THE VEHICLE	18
DOCKING/UNDOCKING THE JAGUAR SMART KEY	18
PROGRAMMING THE REMOTE CONTROL	20
CHANGING THE REMOTE CONTROL BATTERY	21
EMERGENCY KEY BLADE	22

Locks

LOCKING AND UNLOCKING FROM OUTSIDE THE VEHICLE	23
LOCKING AND UNLOCKING FROM INSIDE THE VEHICLE	23
USING THE EMERGENCY KEY BLADE	24
VALET MODE	26
JAGUAR SMART KEY SYSTEM TRANSMITTERS	27
KEYLESS ENTRY	28
GLOBAL OPENING AND CLOSING	29

Alarm

ARMING THE ALARM	30
DISARMING THE ALARM	31
TILT SENSOR	32
INTRUSION SENSOR	32
SENSOR FAULTS	32

Seats

SITTING IN THE CORRECT POSITION	33
ELECTRIC SEATS	34
HEAD RESTRAINTS	36
HEATED SEATS	36
CLIMATE SEATS	37

Seat belts

GENERAL INFORMATION	38
SEAT BELT GUIDE AND RETAINER	39
FASTENING THE SEAT BELTS	40
SEAT BELT REMINDER	40
INERTIA REEL MECHANISM TEST	40
AUTOMATIC LOCKING RETRACTORS	41
USING SEAT BELTS DURING PREGNANCY ...	41

Supplementary restraints system

PRINCIPLE OF OPERATION	42
OCCUPANT SENSING	44
DRIVER AIRBAG	46
PASSENGER AIRBAG	47
SIDE AIRBAGS	48
AIRBAG WARNING LAMP	48
WHIPLASH PROTECTION	48
ROLLOVER BARS	49
AIRBAG LABELS	49
AIRBAG SERVICE INFORMATION	50

Child safety

CHILD SEATS	51
CHILD SEAT POSITIONING	53
BOOSTER CUSHIONS	54
CHILD RESTRAINT TOP TETHER ANCHORAGES	54
ISOFIX ANCHOR POINTS	56

Steering wheel

ADJUSTING THE STEERING WHEEL	60
STEERING COLUMN LOCK	61
HORN	61
HEATED STEERING WHEEL	61
AUDIO CONTROL	62
CRUISE CONTROL	62

Lighting

LIGHTING CONTROL	63
AUTOLAMPS	64
AUTO HIGH BEAM	64
AUTOLAMPS WITH EXIT DELAY	65
DAYLIGHT RUNNING LAMPS	65
CONVENIENCE HEADLAMPS	65
DOOR GUARD AND PUDDLE LAMPS	65
CONDENSATION	65
REAR FOG LAMPS	66
HAZARD WARNING FLASHERS	66
ADAPTIVE FRONT LIGHTING SYSTEM (AFS)	67
DIRECTION INDICATORS	69
INTERIOR LAMPS	70
LAMP FAILURE	71

Wipers and washers

WIPER OPERATION	72
SPEED DEPENDENT MODE	72
RAIN SENSOR	73
WINDSCREEN WASHERS	73
TIMED JET FUNCTION	73
DRIP WIPE	73
HEADLAMP WASHERS	73

Windows and mirrors

ELECTRIC WINDOWS	74
EXTERIOR MIRRORS	77
INTERIOR MIRROR	79

Instruments

INSTRUMENT PANEL OVERVIEW	80
WARNING LAMPS AND INDICATORS	81
AUDIBLE WARNINGS AND INDICATORS	85

Information displays

GENERAL INFORMATION	86
WARNING AND INFORMATION MESSAGES	87
TRIP COMPUTER	88
TOUCH-SCREEN	90
PERSONALISED SETTINGS	92

Climate control

PRINCIPLE OF OPERATION	95
AIR VENTS	96
AUTOMATIC CLIMATE CONTROL	96

Convertible top

OPENING THE CONVERTIBLE TOP	102
PREPARATION FOR WINTER	105
LUGGAGE SEPARATOR	105
CLOSING THE CONVERTIBLE TOP	107

Convenience features

MEMORY FUNCTION	111
INSTRUMENT LIGHTING DIMMER	112
SUN VISORS	112
CLOCK	113
CIGAR LIGHTER	113
ASHTRAY	113
AUXILIARY POWER SOCKET	114
CUP HOLDERS	114
STORAGE COMPARTMENTS	115
CENTRE CUBBY BOX	116
PORTABLE AUDIO INTERFACE	116
GARAGE DOOR TRANSCIVER	117

Starting the engine

GENERAL INFORMATION	120
KEYLESS STARTING	121
SWITCHING OFF THE ENGINE	121

Transmission

AUTOMATIC TRANSMISSION	122
------------------------------	-----

Brakes

PRINCIPLE OF OPERATION	129
HINTS ON DRIVING WITH ABS	129
ELECTRIC PARKING BRAKE (EPB)	131

Parking aids

PRINCIPLE OF OPERATION	132
USING THE PARKING AID	132
REAR VIEW CAMERA	134

Driving hints

RUNNING-IN	136
ECONOMICAL DRIVING	137

Cruise control

PRINCIPLE OF OPERATION	138
USING CRUISE CONTROL	138

Adaptive cruise control (ACC)

PRINCIPLE OF OPERATION	140
USING ACC	140
FORWARD ALERT FUNCTION	146

Automatic speed limiter (ASL)

PRINCIPLE OF OPERATION	148
USING THE ASL	149

Driving dynamics

WINTER MODE	151
DYNAMIC MODE	151
TRAC DSC	151
SWITCHING BETWEEN DSC AND TRAC DSC	151
SWITCHING DSC OFF	152
SWITCHING DSC ON	152
STABILITY CONTROL WARNING LAMPS	152
ADAPTIVE DYNAMICS	152
ACTIVE DIFFERENTIAL CONTROL	152

Fuel and refuelling

SAFETY PRECAUTIONS	154
FUEL QUALITY	154
ALTERNATIVE FUELS	155
RUNNING OUT OF FUEL	156
FUEL FILLER FLAP	156
REFUELLING	157
FUEL TANK CAPACITY	158
FUEL CONSUMPTION	159

Load carrying

GENERAL INFORMATION	160
LUGGAGE COVERS (Coupe only)	160

Vehicle care

CLEANING PRODUCTS	161
CLEANING THE EXTERIOR	161
CLEANING ALLOY WHEELS	163
REPAIRING MINOR PAINT DAMAGE	163
CLEANING THE INTERIOR	164

Maintenance

GENERAL INFORMATION	166
SAFETY IN THE GARAGE	168
OPENING AND CLOSING THE BONNET	169
ENGINE COMPARTMENT OVERVIEW	170
ENGINE OIL CHECK	171
ENGINE COOLANT CHECK	173
BRAKE FLUID CHECK	175
POWER STEERING FLUID CHECK	176
WASHER FLUID CHECK	177
TECHNICAL SPECIFICATIONS	179

Vehicle battery

BATTERY WARNING SYMBOLS	180
BATTERY CARE	180
BATTERY MONITORING SYSTEM (BMS)	181
BATTERY ACCESS	181
CONNECTING BOOSTER CABLES	181
DISCONNECTING THE BOOSTER CABLES	182
CHARGING THE VEHICLE BATTERY	182
CHANGING THE VEHICLE BATTERY	182
EFFECTS OF BATTERY DISCONNECTION	183

Wheels and tyres

TYRE MARKINGS	184
TYRE CARE	185
TYRE PRESSURES	186
TYRE WEAR	188
USING WINTER TYRES	191
USING SNOW CHAINS	192
CHANGING A ROAD WHEEL	192
TYRE REPAIR KIT	198
TYRE PRESSURE MONITORING SYSTEM	202
TYRE GLOSSARY	206
TYRE SPECIFICATIONS - ARDUOUS TERRAIN	207

Fuses

CHANGING A FUSE	208
FUSE BOX LOCATIONS	209
FUSE SPECIFICATION CHARTS	212

Emergency equipment

HAZARD WARNING FLASHERS	216
WARNING TRIANGLE	216
FIRST AID KIT	216
FIRE EXTINGUISHER	216

Status after a collision

DRIVING AFTER A COLLISION	217
PEDESTRIAN PROTECTION SYSTEM	217
AFTER DEPLOYMENT OF THE PEDESTRIAN PROTECTION SYSTEM	217

Vehicle recovery

TRANSPORTING THE VEHICLE	218
TOWING POINTS	218

Vehicle identification

VEHICLE CERTIFICATION LABEL	220
VEHICLE IDENTIFICATION NUMBER (VIN) ...	220
ENGINE NUMBER	220
TRANSMISSION NUMBER	220
VEHICLE BUILT DATE	220

Technical specifications

ENGINE SPECIFICATIONS	221
WEIGHTS	221
DIMENSIONS	222
WHEEL ALIGNMENT DATA (CHINA ONLY) ..	223

Audio unit overview

AUDIO UNIT OVERVIEW	224
---------------------------	-----

Audio unit operation

ON/OFF CONTROL	228
AUDIO CONTROL	228
JAGUAR PREMIUM SURROUND SOUND	231
WAVEBAND BUTTON	233
AUTOSTORE	233
STATION PRESET BUTTONS	233
TRAFFIC INFORMATION CONTROL	234

Audio unit menus

RADIO DATA SYSTEM (RDS)	235
REGIONAL MODE (REG)	237
ENHANCED OTHER NETWORK (RDS-EON) ..	237
ALTERNATIVE FREQUENCIES	238

Digital audio broadcasting

AUDIO CONTROLS	239
DIGITAL RADIO RECEPTION	240
ENSEMBLES	240
DAB INFORMATION PANEL	240
DAB RADIO TEXT	241
CHANNEL AUTOMATIC TUNING	241
CHANNEL OPTIONS	242
PRESET BUTTONS	244
SETTINGS	245

Compact disc player

COMPACT DISC COMPATABILITY	249
LOADING COMPACT DISCS	249
EJECTING COMPACT DISCS	250
COMPACT DISC SELECTION	251
TRACK SELECTION	251
COMPACT DISC PAUSE	252
REPEAT COMPACT DISC TRACKS	252
SHUFFLE/RANDOM	252
COMPACT DISC DISPLAY OPTIONS	253
MP3 FILE PLAYBACK	253

Portable audio

PORTABLE AUDIO	255
PORTABLE AUDIO DEVICES	256

Telephone

GENERAL INFORMATION	261
SAFETY	263
TELEPHONE PAIRING AND DOCKING	263
VOICE MAIL	266
ANSWER OPTIONS	267
PHONE OPTIONS	267
PHONEBOOK	268
MAKING A CALL	270
LAST 10 OPTION	273
HANDS-FREE CONTROLS	273
OTHER FEATURES	275

Navigation system

THE NAVIGATION SYSTEM.....	276
SATELLITE SIGNALS	276
GETTING STARTED	278
MENU STRUCTURE	279
MAIN MENU.....	280
USER SETTINGS.....	280
LANGUAGE SELECTION.....	281
MEASUREMENT UNITS	281
KEYBOARD LAYOUT	281
MAP SPLIT SCREEN.....	282
MAP DISPLAY ICONS	283
SEARCH AREA	284
SETTING A DESTINATION.....	285
ROUTE PREFERENCES	287
START GUIDANCE	288
VOICE GUIDANCE	289
CANCEL GUIDANCE	289
QUICK POI SELECTION	290
CALIBRATION	290
RESTORE SYSTEM DEFAULTS	291
LANGUAGE SELECTION.....	292
STORED LOCATIONS	292
AVOID POINTS.....	294
HOME	294
DESTINATION ENTRY	294
POSTCODE	295
MAP	295
COORDINATES	296
POINTS OF INTEREST (POI)	296
PREVIOUS	297
MOTORWAY	297
COMPASS.....	298
POINTS OF INTEREST.....	299
POI ICON DISPLAY	300
CANCELLING POI ICON DISPLAY	302
JAGUAR DEALERSHIP LOCATIONS.....	302
ENTRY BY TOWN.....	302
ENTRY BY CATEGORY	302
OTHER SELECTION METHODS	302
CATEGORIES AND SUB-CATEGORIES	302
POI ENTRY MESSAGES	303
QUICK POI SELECTION	303
SELECTING A QUICK POI CATEGORY.....	303
MEMORY POINTS.....	304

RDS-TMC OVERVIEW.....	304
USING TMC	306
SURVEILLANCE SETTING.....	307
ORDNANCE SURVEY DATA.....	309
NAVTEQ CORPORATION	310
EUROPEAN DECLARATION OF CONFORMITY	311

Appendices

TYPE APPROVALS	312
----------------------	-----

