

The vehicle will only lock if both doors, the luggage compartment and the bonnet are closed. If a lock attempt is made with an open aperture, the vehicle will not lock and two audible error warnings will sound.

To lock the vehicle, press the button on the door handle. The hazard warning lamps will flash once as confirmation.

Note: *Keyless locking will only activate if the Jaguar Smart Key is outside the vehicle. If no Smart Key is present, two audible error warnings will sound.*

Window global closing

Press and hold the button on the door handle for three seconds, to lock the vehicle, arm the alarm and also close all open windows. The windows will stop closing when the button is released.

Convenience mode

When the door is opened using either the Jaguar Smart Key or keyless entry, the vehicle's electrical system initiates the convenience mode. The following systems become functional:

- Memory.
- Seat and steering column adjustment.
- Interior and exterior lighting.
- Message centre.
- Auxiliary power socket.

GLOBAL OPENING AND CLOSING

WARNINGS



Accidental closing of an electrically operated window on fingers, hands or any vulnerable part of the body, can result in serious injury.

WARNINGS



Make sure that you have a clear view of all open apertures on the vehicle and that all apertures are unobstructed, before activating the global closing.

Global opening and closing is enabled/disabled via the touch-screen. See **PROGRAMMING THE REMOTE CONTROL** (page 20).

Window global opening

Window Global open can be performed by pressing and holding the unlock button on the Jaguar Smart Key. This can be cancelled by pressing any button on the Smart Key while the windows are moving.

Window global closing

Window global close can be performed by pressing and holding the lock button on the Jaguar Smart Key. This can be cancelled by pressing any button on the Smart Key while the windows are moving.

Alternatively, press and hold the exterior locking button on the driver's door handle for at least three seconds (with a valid Jaguar Smart Key in the vicinity of the door) until all the windows are closed.

Note: *The windows will stop closing when the lock button is released.*

Cancelling window global open/close

To stop the windows from opening/closing during a global open/close, press any of the buttons on the Jaguar Smart Key or operate the driver's window switch. To stop a particular window from opening/closing, operate the relevant window switch.