



## Recalling a preset channel



JAG1401


Make sure that you have selected the appropriate digital source (**DAB1**, **DAB2** or **DAB3**) and then briefly touch the preset button you require. The channel you have selected will start to play automatically.



JAG1402


**Note:** If you try to recall a channel that has previously been stored as a preset, but is now unavailable or invalid, the message **No channel found** is displayed. You must choose another channel.

## SETTINGS



JAG1403

In DAB mode, select **Settings**.



JAG1404

Select **Options**.

**Note:** If **Settings** is selected once, but no action is taken for a further ten seconds, the system will exit the menu automatically.


## Announcements

You can select up to four types of announcement from a list of eleven, for example, **News**, **Area/Weather**, **Traffic** and **Alarm**.

When a DAB announcement is broadcast, it will interrupt normal play for the duration of the announcement.


**Note:** The **Alarm** announcement type, broadcasts information concerning crises of national or international importance.

# Digital audio broadcasting



JAG1405

To display the full list of announcement types, touch **Select**.




JAG1406

Select an announcement type to enable it, select it again to disable it. If you want to clear all enabled types, select **Clear all**. To scroll through the list, select the arrow buttons.

**Note:** If you have already selected four announcement types, you will be unable to select further types.

## FM traffic

The **FM traffic** option detects the presence of local traffic announcements on FM stations. As soon as an announcement is received, radio reception or CD play will be interrupted. At the end of the announcement, radio or CD play will resume.



JAG1407


Select **On** or **Off** to enable or disable the FM traffic option.

**Note:** The audio unit switches to an FM broadcast for the duration of the announcement, so there may be a temporary loss of sound quality.

## Link DAB

Regional ensembles containing a list of local digital channels are broadcast by a variety of regional providers. For example, the Leicester and Coventry regions in the UK are currently supplied by Now Digital, whereas Birmingham is supplied by CE Digital.

A channel (for example, Chill) in two different regional ensembles will share an identification if broadcast by the same provider (for example, Chill Coventry and Chill Leicester). If channels are being broadcast by different suppliers, then they will not share the same identification (for example, Chill Coventry and Chill Birmingham).



JAG1408

If you move from one region to another and **Link DAB** is enabled, the DAB radio will attempt to retune to a channel with the same identification in a different ensemble.


If the signal strength for a local channel falls below an acceptable level, the audio unit will automatically search other available ensembles for another channel with the same identification.

If an alternative channel is found in another ensemble that is also in your current channel list, then the new channel is tuned automatically after a few seconds. If a channel is not found after a few seconds, then **No reception** is displayed on the screen.

The word **Link** is displayed at the top of the touchscreen to indicate that Link DAB is enabled.

## DAB text

The DAB text option controls the type of information that is displayed on the screen when a channel or subchannel is playing.






JAG1409

- Select **Ensemble** to display the name of the ensemble to which the current channel belongs.
- Select **PTY** to display the name of the programme type to which the current channel belongs.
- Select **Off** to display only the channel name.

## DAB country

If you move the vehicle to a different country, you can change DAB Country options to make sure that you receive the best possible reception and sound quality.

**Note:** If you have already selected a DAB format, then the DAB country option is disabled.





JAG1410

Select **Change** to display a list of countries where DAB services are available. Select the country name to enable it.

**Note:** When you change the DAB country, the audio unit will automatically start auto-tuning. If you **Cancel** the auto-tune, the country setting will remain changed but you may not have access to all available ensembles for that country. See **CHANNEL AUTOMATIC TUNING** (page 241).

**Note:** This option is disabled when the vehicle is moving

## DAB format



JAG1411

Different regions or countries may use different digital bands to broadcast DAB channels. If you know the band(s) required, then you can choose from the **Band selection list**.

Select **Change** to display a list of formats. The available bands are:

- L Band
- Band III
- L Band & Band III
- L Band Canada
- L Band Can & Band III

**Note:** When you change the DAB format, the audio unit will automatically start auto-tuning. If you **Cancel** the auto-tune, the format setting will stay changed but you may not have access to all available ensembles for that format. See **CHANNEL AUTOMATIC TUNING** (page 241).

**Note:** This option is disabled when the vehicle is moving