


## MAP SCREEN



SJ1748

1. Compass (set to North is up). Touch to toggle between this and the small compass which always indicates north (12).
2. Zoom and scale display.
3. Distance display.
4. Menu, touch to access Main menu, see **113, MAIN MENU**.
5. Screen mode selection: Touch to select alternative screen options (split screen option shown above), see **117, SCREEN MODES**.
6. Current street location.
7. POI symbol, see **120, POINTS OF INTEREST (POI)**.
8. Split screen.
9. TMC symbol, see **123, RDS-TMC ICONS**.
10. Current vehicle position and direction of travel.
11. Next direction display.
12. Compass, always indicates north.
13. Message area.
14. **GPS** (Global Positioning System), with red arrow indicates a signal is not being received.
15. **TMC** (Traffic Master Channel), with red arrow indicates a signal is not being received.