

Controls overview

DRIVER CONTROLS

1. Front map reading lamps (32).
2. Front courtesy lamps (32).
3. Garage door opener (40).
4. Convertible roof switch (59).
5. Parking aid (81).
6. Trip computer (48).
7. Indicator/headlamp control (30).
8. Gearshift down (71).
9. Instrument panel.
10. Gearshift up (71).
11. Wipers/washers (34).
12. Touch screen (50).
13. Hazard warning lamps on/off.
14. Glove box release.
15. Home menu (50).
16. Passenger airbag off (28).
17. Engine START/STOP button (68).
18. Gear selector (72).
19. Stability control (DSC) (74).
20. Speed limiter (ASL) (90).
21. Parking brake (78).
22. Dynamic mode (74).
23. Winter mode (74).
24. Climate controls (54).
25. Audio controls (91).
26. Touch screen on/off (50).
27. Cruise control or ACC controls (83/ 85).
28. Horn/airbag (27).
29. Steering column adjuster (16).
30. Audio controls (91).
31. Bonnet release (144).
32. Instrument illumination - rotate to adjust.
33. Front fog lamps on/off.
34. Rear fog lamps on/off.
35. Boot release (57).
36. Forward alert switch (89).
37. Fuel filler flap release (135).
38. Window controls (36).
39. Mirror controls (38).
40. Seat position switches (12).
41. Driving position memory (13).

