

Valet on is displayed to indicate that the PIN has been accepted. The luggage compartment and glove box are now securely locked in Valet mode.

On exiting and securing the vehicle (with the emergency key removed). Retain the emergency key and give the Jaguar Smart Key to the attendant.

Note: *The emergency key can be used to open the luggage compartment, which may de-activate Valet mode.*

DESELECTING VALET MODE

When you enter the vehicle, select the Valet mode screen.

Enter your four digit PIN and touch the **OK** button. A pop-up is displayed. Read the information and replace the emergency key.

Valet off is displayed to indicate that your PIN has been accepted.

- The luggage compartment will return to the previously set security requirement.
- The glove box will now open as normal.

Note: *If the PIN is forgotten, open the luggage compartment using the emergency key blade to cancel Valet mode, see 57, **OPENING AND CLOSING THE LUGGAGE COMPARTMENT.***