

Note: Three different exterior mirror positions can be stored and recalled using the driving position memory feature. See **13, DRIVING POSITION MEMORY**.

MIRROR DIP WHEN REVERSING

The mirrors can be configured so that when reverse gear is selected, the passenger door mirror automatically adjusts to provide an improved viewing angle for reversing.

The exact dipped position can be adjusted using the joystick control, when the mirror is dipped. The next time reverse is selected, the newly adjusted position will be selected.

When the gear selector is moved out of reverse, or if vehicle speed exceeds 7 km/h (4 mph) while reversing, the mirror will return to its previous position.

Mirror dip can be selected or deselected using the touch screen:

From the main **Home** menu, select **Vehicle**:

- Select **Veh. settings**.
- The **Security** screen is selected automatically as the default.
- Select **Parking**.
- Select **Reverse mirror dip On** or **Off**.