


INFORMATION DISPLAY

The driver message and information display is situated within the instrument panel.

The primary function of the message centre is to inform the driver of the following:

- Warning messages.
- Temporary alert messages.
- Information messages.
- Turn-by-turn navigation information.



1. Gear selection, automatic or manual.
2. Speed control related information.
3. Priority warning indicators.
4. Warning messages (red or amber), if system faults are detected. Status messages are displayed to indicate changes in state of certain vehicle functions (e.g. navigation, telephone).

When there are no current warning messages, turn-by-turn navigation information is displayed. This facility can be turned off via the touch-screen.

As an option the clock can be displayed.

5. Trip computer information, including digital speedometer and total distance covered by the vehicle. See **48, TRIP COMPUTER**.
6. Set trip computer information display to **A, B** or **Auto** trip computer. See **48, TRIP COMPUTER**. When selected using the trip computer button, this area also shows the current electronic engine oil dipstick reading. See **146, CHECKING THE ENGINE OIL LEVEL**.
7. The fuel level gauge, which changes colour from blue to red when the fuel drops to the reserve fuel level indicator. The small arrow on the top of the fuel pump symbol denotes which side of the vehicle the fuel filler cap is located.

WARNING AND INFORMATION MESSAGES



Do not ignore warning messages. Take appropriate action and, when necessary, seek qualified assistance before driving the vehicle.

Most warning messages, when displayed, have an associated warning indicator (red or amber) that will illuminate to indicate the message priority. Information messages will also be displayed.

If more than one message is active, each is displayed in turn for 2 seconds in order of priority.

Note: *The message centre messages and their meanings, are detailed where necessary within the appropriate subject sections.*

It is possible to temporarily clear certain warning or information messages from the message centre.