

# Controls overview

## DRIVER CONTROLS

1. Front map reading lamps (40).
2. Front courtesy lamps (40).
3. Garage door opener (48).
4. Convertible roof switch (68).
5. Parking aid (92).
6. Trip computer (57).
7. Indicator/headlamp control (38).
8. Gearshift down (80).
9. Instrument panel.
10. Gearshift up (80).
11. Wipers/washers (42).
12. Touch screen (59).
13. Hazard warning lamps on/off.
14. Glove box release.
15. Home menu (59).
16. Passenger air bag off (36)
17. Engine START/STOP button (77).
18. Gear selector (81).
19. Stability control (DSC) (84).
20. Speed limiter (ASL) (102).
21. Parking brake (87).
22. Dynamic mode (83).
23. Winter mode (83).
24. Climate controls (63).
25. Audio controls (103).
26. Touch screen on/off (59).
27. Cruise control or ACC controls (95/ 97).
28. Horn/air bag (33).
29. Steering column adjuster (21).
30. Audio controls (103).
31. Hood release (157).
32. Instrument illumination - rotate to adjust.
33. Rear fog lamps on/off.
34. Trunk release (66).
35. Forward alert switch (101).
36. Fuel filler flap release (148).
37. Window controls (44).
38. Mirror controls (46).
39. Seat position switches (16).
40. Driving position memory (17).

