

EC-Declaration of Conformity

Manufacturer: Valco Raytheon Systems, Inc.
EU: Lehmsstrasse 12, 74321 Bietigheim-Bissingen, Germany
(USA: 150 Stephenson Highway, Troy, MI 48063 USA)

Address/Location

Declares that the product:

type: MultiBeam Radar 24GHz
model: MBR Gen2
Intended use: Blind Spot Detection

complies with the essential requirements of Article 3 of the R&TTE 1999/SEC Directive, if used for its intended use and that the following standards has been applied:

- | | | | | |
|--|------------------|--|-------|--------------------------------|
| 1 Health (Article 3.1 of the R&TTE Directive) | Applied Standard | <u>EN 50385</u> | Issue | <u>2002</u> |
| 2 Safety (Article 3.1 of the R&TTE-Directive) | Applied Standard | <u>EN 60950-1</u> | Issue | <u>2006</u> |
| 3 Electromagnetic Compatibility (Article 3.1.b of the R&TTE-Directive) | Applied Standard | <u>ETSI EN 301 489-1</u>
<u>ETSI EN 301 489-3</u> | Issue | <u>V1.6.1</u>
<u>V1.4.1</u> |
| 4 Efficient Use of the radio frequency spectrum (3.2 of the R&TTE-Directive) | Applied Standard | <u>ETSI EN 300 440-1</u>
<u>ETSI EN 300 440-2</u> | Issue | <u>V1.3.1</u>
<u>V1.1.2</u> |

10/10/2007 Eric Amiot



(Place and date of the declaration of conformity)

(Name and signature)

A

ABS (Anti-lock braking system)	
warning lamp	54
ACC (Adaptive cruise control)	96
automatic switch-off	98
driving hints	98
fault	99
follow mode	96
gap change	97
low speed switch-off	98
malfunction	99
operating	96
override	97
resume follow mode	98
resume set speed	98
warning lamp	55
Active differential control	85
Adaptive front lighting system (AFS)	
warning lamp	55
AFS (Adaptive front lighting system)	39
After a collision	
pedestrian protection system	203
Age degradation (tyres)	188
Air conditioning	
air quality sensor	65
Air quality sensor	65
Airbags	
module covers	164
SRS (Supplementary restraint system)	155
warning lamps	55
Alarm	11, 155
automatic relocking and arming	12
battery backed sounder	11
deactivating	12
passive arming	12
perimeter	11
sensor fault	12
tilt sensor	12
Anchor points (luggage)	69
Antifreeze level check	167
Anti-theft system	155
Anti-trap mechanism	
sunroof	45

Anti-trap protection	
windows	45
Approach lamps	39
Arduous driving conditions	156
ASL (Automatic speed limiter)	
warning lamp	55
Audible warnings	57
Audio	
Settings	104
Audio system	163
Audio/video	
controls	103
portable media	
connections	115
controls	113
pairing	117
play	116
television	
controls	119
video media player	
controls	121
Automatic gearbox	81
Automatic locking	8
Automatic switch off (ACC)	98
Auxiliary devices	
connecting multiple devices	116

B

Battery	
care	178
changing	
timed climate remote	180
charging	180
jump starting	
connecting cables	179
disconnecting cables	180
monitoring system	179
warning symbols	178
Battery backed sounder	11
Beltminder	
warning lamp	54

Index

- Belts 164
 - seatbelt warning lamp 54
- Bluetooth 126
 - audio
 - pairing 117
 - media
 - pairing 117
 - telephone
 - compatibility 127
 - icons 129
 - overview 126
 - pairing 128
 - phonebook 130
 - safety 127
- Bonnet
 - closing 157
 - opening 157
- Boost starting 179, 180
- Brakes
 - ABS warning lamp 54
 - advanced emergency assist 100
 - EBA (Emergency brake assist) 88
 - EBD (Electronic brake force distribution) 88
 - handbrake 88
 - pedal travel 177
 - warning lamp 53
- BSM (Blind spot monitor) 48
- Bulbs
 - license plate 160
 - number plate 160
- C**
- Call volume 130
- Capacities 176
- Carpets and mats 163
- Car-wash 162
- Changing a fuse 192
- Changing the battery (timed climate) ... 180
- Charging the vehicle battery 180
- Cleaning
 - alloy wheels 161
 - carpets and mats 163
 - exterior 161
 - paintwork 161
 - glass 162
 - interior 162, 163
 - leather 163
 - parking sensors 94
 - polishing 162
 - rear screen 162
 - removing grease 162
 - removing stains 163
 - removing tar 162
 - sunroof 162
 - underbonnet 162
 - using a car-wash 162
- Climate seats 66
- Clock 163
- Closing
 - alarm sensor faults 12
 - single locking 10
- Closing the bonnet 157
- Closing the luggage compartment 67
- Condensation (headlamps) 40
- Conformity declarations 144, 207
- Consumption
 - fuel
 - urban cycle 154
- Consumption (fuel) 154
- Controls
 - headlamps 38
- Coolant
 - checking the level 167
 - specification 167
 - top up 167

- Cruise control
 - ACC (Adaptive cruise control) 96
 - low speed switch-off 98
 - malfunction 99
 - operating 96
 - override 97
 - resume follow mode 98
 - resume set speed 98
 - follow mode 96
 - operating 95
- D**
- DAB
 - ensembles 112
- DAB radio
 - controls 110
- Daily checks 155
- Data recording 203, 204
- Daylight running lamps 39
- Dealer locations 139
- Declarations of conformity 207
 - navigation system 144
- Derv
 - sulphur content 151
- Deselecting valet mode 63
- Destination entry 135
 - postcode 137
 - search area 135
- Detection beam issues 99
- Diesel
 - engine 151, 152
 - switching off 77
 - filler flap 152, 153
 - fuel consumption 154
 - misfuel device 153
 - specification 154
 - sulphur content 151
 - water in fuel 151
- Diesel particulate filter (DPF) 156
- Differential control 85
- Dimensions 174
- Direction indicators 39
 - warning lamp 56
- Disability modifications 155
- Door transceiver
 - entry gate 52
 - garage door opener 50
 - programming 50
 - programming a single button 51
 - rolling code device programming 51
- Double locking 10
- DPF (Diesel particulate filter) 156
- Drive away locking 8
- Drive control
 - operation 86
- Driver controls 228
- Driver information module
 - warning lamps 53
- Driving
 - ACC (Adaptive cruise control) 96, 98
 - override 97
 - adaptive cruise control
 - automatic switch off 98
 - arduous conditions 156
 - before starting 203
 - controls 228
 - daily checks 155
 - DSC warning lamp
 - active 55
 - off 55
 - dynamic mode 84
 - EBA (Emergency brake assist) 88
 - EBD (Electronic brake force distribution) 88
 - forward alert 100
 - mirror dip when reversing 47
 - sitting correctly 15
 - wipers
 - rain sensor 42
- Driving abroad
 - headlamps 40

Index

- DSC (Dynamic stability control)
 - switching between DSC and tracDSC . . . 85
 - switching off 85
 - switching on 85
 - warning lamp
 - active 55
 - off 55
- Dynamic mode 84
- E**
- EBA (Emergency brake assist) 88
- EBD (Electronic brake force distribution) . . 88
- Electric seats
 - front 13
- Electronic brake force distribution (EBD) . . 88
- Electronic data 204
- Electronic parking brake (EPB) 88
- Emergency
 - jump starting
 - connecting cables 179
 - disconnecting cables 180
- Emergency brake assist (EBA) 100
- Engine
 - compartment
 - cleaning 162
 - fuse box 193
 - opening 157
 - overview 157
 - coolant level checking 167
 - diesel 151, 152
 - DPF (Diesel particulate filter) 156
 - engine compartment 157
 - failure to start 78
 - oil level check 165
 - specifications 171
 - switching off 77
- Ensembles (DAB radio) 112
- Entering a destination 135
- Entering the vehicle
 - entry and exit mode 23
 - keyless entry 7
- Entertainment
 - DAB radio
 - controls 110
 - navigation
 - coordinates 138
 - menu 133
 - motorway 138
 - POI categories 139
 - POI (Points of interest) 137, 138
 - postcode 137
 - previous 138
 - restore defaults 137
 - TMC 139
 - TMC display 140
 - TMC icons 140
 - portable media
 - changing device 118
 - connecting devices 116
 - connecting multiple devices 116
 - connections 115
 - controls 113
 - lost connection 118
 - pairing 117
 - playing 116
 - radio
 - controls 108
 - RDS (Radio data system) 109
 - RSE (Rear screen entertainment)
 - screen settings 61
 - telephone
 - pairing 128
 - phonebook 130
 - television
 - controls 119
 - touch screen 163
 - home menu 60
 - operating 61
 - setup 61
 - system settings 61
 - touch screen care 61
 - video media player
 - controls 121
 - Entry and exit mode 23

- EPB (Electric parking brake) 88
- Ethanol 150
- EU conformity (navigation system) 144
- Event data recording 204
- Exiting the vehicle
- door locks and release levers 10
 - global closing 11
 - keyless locking 11
- Exterior cleaning 161
- Exterior mirrors 46
- Extinguisher 161
- F**
- Faulty alarm sensors 12
- Fire extinguisher 161
- First aid kit 161
- Flat spots 188
- Fluids
- capacities 176
 - coolant
 - specification 167
 - top up 167
 - engine oil
 - check 165
 - fuel tank capacity 154
 - power steering
 - check 169
 - specification 170
 - specifications 172
 - washer
 - specification 170
 - top up 170
- Fog lamps
- warning lamp 55
- Follow mode
- entering 96
 - gap change 97
 - override 97
 - resume 98
- Forward alert 100
- Front parking aid 93
- system fault 94
- Fuel and refuelling
- consumption 154
 - extra-urban cycle 154
 - urban cycle 154
 - diesel 151
 - sulphur content 151
 - ethanol 150
 - Filler flap 153
 - filler flap 152
 - fuel consumption
 - urban cycle 154
 - fuel specification 154
 - fuel system 157
 - methanol 150
 - misfuel device 153
 - MTBE (Methyl tertiary butyl ether) 151
 - octane rating 150
 - running out 151
 - safety precautions 150
 - tank capacity 154
 - water in fuel 151
- Fuses
- changing 192
 - engine compartment fuse box 193
 - locations 192
 - luggage compartment fuse box 196
 - Passenger compartment fuse box 195
- G**
- Garage door opener 50
- entry gate 52
 - erase all programming 51
 - programming 50
 - a single button 51
 - rolling code device 51
- Gear selector 82

Index

Gearbox	
automatic	81
limp home mode	83
operation	86
selector	82
temporary manual selection	82
winter mode	84
Glass cleaning	162
Global closing	11
Global opening	7

H

Handbrake	88
Handling	
DSC warning lamp	
active	55
off	55
dynamic mode	84
EBD (Electronic brake force distribution)	88
Head restraints	21
manual	21
Headlamps	
adaptive	39
AFS (Adaptive front lighting system)	39
approach lamps	39
condensation	40
controls	38
daylight running lamps	39
driving abroad	40
high beam warning lamp	56
warning lamp (AFS)	55
washers	43
wiper detection	39
Heated seats	66
Heated steering wheel	23
High beam	
warning lamp	56
Homelink	50
programming a single button	51
rolling code device programming	51

I

Ignition	
rolling re-start	78
switching on	77
Indicators	39
warning lamp	56
Infotainment	
DAB radio	
controls	110
navigation	
coordinates	138
menu	133
motorway	138
POI categories	139
POI (Points of interest)	137, 138
postcode	137
previous	138
restore defaults	137
TMC	139
TMC display	140
TMC icons	140
portable media	
changing device	118
connecting devices	116
connecting multiple devices	116
connections	115
controls	113
lost connection	118
pairing	117
playing	116
radio	
controls	108
RDS (Radio data system)	109
RSE (Rear seat entertainment)	
screen settings	61
telephone	
pairing	128
phonebook	130
television	
controls	119
touch screen	163
home menu	60
operating	61

- setup 61
 - system settings 61
 - touch screen care 61
 - video media player
 - controls 121
 - Inhibited media playback 122
 - Instrument pack 163
 - Instrument panel
 - lamp test 53
 - warning lamps 53
 - Interior cleaning 162, 163
 - carpets and mats 163
- J**
- Jaguardrive control
 - operation 86
 - Jump starting 179, 180
- K**
- Keyless entry 7
 - Keyless locking 11
 - Keys
 - single locking 10
- L**
- Lamp test 53
 - Lamps
 - condensation 40
 - controls 38
 - warning lamps 53
 - TPMS (Tyre pressure monitoring system)
 - 55
 - wiper detection 39
 - Leather cleaning 163
 - License plate bulb 160
 - Lights
 - condensation 40
 - controls 38
 - Limp home mode 83
 - Load securing 69
- Locking
 - alarm sensor faults 12
 - automatic relocking 12
 - confirmation 10
 - door locks and release levers 10
 - double locking 10
 - drive away 8
 - global closing 11
 - keyless 11
 - mislock 10
 - Locking and unlocking
 - alarm
 - perimeter 11
 - sensor faults 12
 - passive arming 12
 - single locking 10
 - unlocking 5
 - Lubricants
 - specifications 172
 - Luggage
 - anchor points 69
 - Luggage compartment
 - closing 67
 - fuse box 196
 - opening 67

- M**
- Maintenance**
- blocked washer jets 159
 - capacities 176
 - changing a fuse 192
 - checking the tyre pressures after a repair 148
 - cleaning
 - polishing 162
 - removing grease and tar 162
 - removing stains 163
 - cleaning alloy wheels 161
 - cleaning glass 162
 - cleaning parking sensors 94
 - cleaning rear screen 162
 - closing the bonnet 157
 - coolant level checking 167
 - daily checks 155
 - DPF 156
 - engine compartment 157
 - exterior cleaning 161
 - fuse box (luggage compartment) 196
 - interior cleaning 162, 163
 - jump starting
 - connecting cables 179
 - disconnecting cables 180
 - leather cleaning 163
 - lubricants and fluid specifications 172
 - number plate bulb 160
 - paintwork repair 161
 - smart key battery changing 8
 - sunroof wind deflector 162
 - weekly checks 155
- Manual head restraints** 21
- Map (navigation system)** 138
- Map split screen (navigation system)** 134
- Media** 122
- inhibited 122
 - portable
 - lost connection 118
 - play 116
 - portable media
 - connections 115
- Memory seats**
 - recalling a position 15
- Methanol** 150
- Minor paintwork damage repair** 161
- Mirrors**
 - BSM (Blind spot monitor) 48
 - dip when reversing 47
- Mirrors and windows**
 - exterior mirrors 46
 - sunroof
 - anti-trap mechanism 45
 - reset 160
- Misfuel device** 153
- Modifications for disabilities** 155
- Monitoring system (battery)** 179
- Moon roof**
 - anti-trap mechanism 45
 - reset 160
- mpg** 154
- MTBE (Methyl tertiary butyl ether)** 151

N

Navigation

cancel guidance	137
destination entry	135
coordinates	138
emergency	138
motorway	138
postcode	137
previous	138
search area	135
start guidance	136
map	138
map split screen	134
menu	133
operating	132
overview	131
POI (Points of interest)	138
categories/sub-categories	139
quick POI selection	137
POI search	139
restore defaults	137
screen modes	135
TMC	139
display	140
icons	140
using TMC	141
voice commands (POI)	124
voice guidance	137
Number plate bulb	160

O

Occupant safety

seatbelts	164
warning lamp	54

Oil

engine	
level check	165
engine oil specification	166
used engine oil	157
One-touch operation (windows)	45

Opening

alarm sensor faults	12
bonnet	157
luggage compartment	67
Overriding speed and follow mode (cruise)	97

P

Paddle shift

temporary manual selection	82
----------------------------	----

Paintwork

cleaning	161
repair	161

Parking aid

operating	93
sensor cleaning	94
system fault	94

Parking brake

	88
--	----

Passenger compartment fuse box

	195
--	-----

Passive arming

	12
--	----

Pedestrian protection system

after deployment	203
------------------	-----

Perimeter alarm

	11
--	----

Petrol

consumption	154
engine	
switching off	77
octane rating	150
specification	154

Petrol filler flap

	152, 153
--	----------

Phone

bluetooth	126
call volume	130
changing connected phone	129
compatibility	127
controls	
steering wheel	130
icons	129
overview	126
pairing using touch screen	128
phonebook	130
safety	127

Index

- POI (Points of interest) 138
 - search 139
 - Portable media
 - changing device 118
 - connecting devices 116
 - connecting multiple devices 116
 - connections 115
 - controls 113
 - lost connection 118
 - pairing 117
 - playing 116
 - Power steering
 - fluid
 - check 169
 - specification 170
 - Pressures
 - checking
 - after a repair 148
 - tyres 183
 - Previous destination (navigation system) 138
 - Programming
 - garage door opener 50
 - erase all 51
 - Puncture repair kit 145
 - instructions for use 146
 - repair procedure 147
 - safety 145
 - Punctured tyres 188
- ## R
- Radio
 - controls 108
 - DAB ensembles 112
 - RDS (Radio data system) 109
 - Rain sensor 42
 - RDS (Radio data system) 109
 - RDS-TMC 139, 141
 - display 140
 - icons 140
 - Rear media
 - screen settings 61
 - Rear screen cleaning 162
 - Recalling seat memory position 15
 - Recording
 - service data 203
 - Recovery
 - towing eyes 202
 - transporting 202
 - Refuelling
 - diesel 151
 - sulphur content 151
 - octane rating 150
 - running out of fuel 151
 - safety precautions 150
 - Remote control
 - battery changing 8
 - care 8
 - system transmitters 177
 - Repairing paintwork damage 161
 - Replacement tyres 188
 - Resetting the windows 161
 - Restarting the engine whilst moving 78
 - Restore default settings (navigation system) 137
 - Resume speed and follow mode (ACC) 98
 - Reverse parking aid 93
 - system fault 94
 - Rolling re-start 78
 - RSE (Rear seat entertainment)
 - screen settings 61
 - Running out of fuel 151
- ## S
- Safety
 - fuel and refuelling 150
 - in the garage 156
 - seatbelts 164
 - warning lamp 54
 - sitting correctly 15
 - tyre care 182
 - used engine oil 157
 - using the telephone 127
 - warning triangle 161

- Satellite navigation
 - cancel guidance 137
 - destination entry 135
 - coordinates 138
 - postcode 137
 - previous 138
 - search area 135
 - start guidance 136
 - emergency 138
 - map 138
 - map split screen 134
 - menu 133
 - motorway 138
 - operating 132
 - overview 131
 - POI (Points of interest) 138
 - categories 139
 - quick POI selection 137
 - POI search 139
 - restore defaults 137
 - screen modes 135
 - TMC 139
 - display 140
 - icons 140
 - using TMC 141
 - voice commands (POI) 124
 - voice guidance 137
- Screen modes (navigation system) 135
- Search area (navigation system) 135
- Seatbelts 164
 - beltminder warning lamp 54
 - warning lamp 54
- Seats
 - climate 66
 - electric
 - front 13
 - head restraints 21
 - heated 66
 - manual head restraints 21
 - memory
 - recalling a position 15
 - rear
 - safety 17
 - seatbelts 164
 - warning lamp 54
 - sitting correctly 15
- Securing luggage 69
- Security 11
 - alarm 155
 - passive arming 12
 - perimeter 11
 - tilt sensor 12
 - automatic relocking and arming 12
 - battery backed sounder 11
 - deactivating the alarm 12
 - lock confirmation 10
 - sensor faults 12
- Selecting valet mode 63
- Sensors
 - security sensor faults 12
- Servicing
 - data recording 203
- Setting a destination (navigation) 135
- Settings
 - rear media 61
 - vehicle 62
- Silencing the alarm 12
- Sitting correctly 15
- Smart key
 - battery changing 8
 - care 8
 - single locking 10
 - transmitters 177
- Snow chains 190

Index

- Specifications
 - brake pedal travel 177
 - dimensions 174
 - engine 171
 - ethanol 150
 - fluids 172
 - washer 170
 - fuel 154
 - Fuel tank capacity 154
 - lubricants 172
 - methanol 150
 - weight 173
 - Speed-dependent wipers 42
 - Split screen map 134
 - SRS
 - Airbags 155
 - SRS (Supplementary restraint system)
 - airbag covers 164
 - airbag warning lamp 55
 - seatbelts (beltminder) warning lamp . . . 54
 - Stability control
 - switching between DSC and tracDSC . . . 85
 - switching off 85
 - switching on 85
 - tracDSC 84
 - switching between tracDSC and DSC. . 85
 - Starting
 - preparation 203
 - Starting navigation guidance 136
 - Steering wheel
 - adjusting 23
 - controls
 - connect phone call 130
 - decrease volume 130
 - disconnect phone call 130
 - increase volume 130
 - scroll/search down 130
 - voice control talk 130
 - heated 23
 - Steering wheel controls 130
 - Storage compartments 75
 - cup holders 75
 - front cubby box 75
 - glove box 75
 - rear armrest 75
 - Sunroof
 - anti-trap mechanism 45
 - reset 160
 - Switching off the engine 77
 - Switching on the ignition 77
- ## T
- Technical specifications
 - weights 173
 - Telephone
 - bluetooth 126
 - call volume 130
 - changing the connected telephone 129
 - compatibility 127
 - controls
 - steering wheel 130
 - icons 129
 - overview 126
 - pairing 128
 - phonebook 130
 - safety 127
 - Television
 - controls 119
 - Tilt sensor 12
 - Timed jet function 43
 - TMC (Traffic message channel) 141
 - display 140
 - overview 139
 - TMC (Traffice message channel)
 - icons 140

- Touch screen 163
 - home menu 60
 - navigation
 - coordinates 138
 - menu 133
 - motorway 138
 - POI categories 139
 - POI (Points of interest) 137, 138
 - postcode 137
 - screen modes 135
 - search area 135
 - TMC 139
 - TMC display 140
 - TMC icons 140
 - operating 61
 - portable media
 - changing device 118
 - connecting devices 116
 - connecting multiple devices 116
 - connections 115
 - controls 113
 - lost connection 118
 - pairing 117
 - playing 116
 - RSE (Rear seat entertainment)
 - screen settings 61
 - setup 61
 - system settings 61
 - telephone
 - pairing 128
 - phonebook 130
 - television
 - controls 119
 - touch screen care 61
 - valet mode 63
 - vehicle settings 62
 - video media player
 - controls 121
- Tow eye (front) 202
- Towing eyes 202
- TPMS (Tyre pressure monitoring system)
 - tyre care 182
 - valves 188
 - warning lamp 55
- tracDSC 84
 - switching between DSC and tracDSC 85
- Traction control
 - switching between DSC and tracDSC 85
 - switching off 85
 - switching on 85
 - tracDSC 84
 - switching between tracDSC and DSC 85
- Transmission
 - gear selector 82
 - limp home mode 83
 - operation 86
 - temporary manual selection 82
 - winter mode 84
- Transmission (automatic) 81
- Transmitters
 - smart key 177
- Transporting the vehicle 202
- Trim
 - airbag covers (cleaning) 164
- TV
 - controls 119
- Tyre pressure checking after repair 148
- Tyre repair kit
 - repair procedure 147

Index

Tyres

age degradation	188
flat spots	188
pressures	183
punctured	188
repair kit	145, 146
repair procedure	147
safety	145
replacements	188
snow chains	190
TPMS (Tyre pressure monitoring system)	
warning lamp	55
tyre care	182
valves	188
winter	189

U

Underbonnet cleaning	162
Unlocking	5, 10
alarm sensor faults	12
entry and exit mode	23
global opening	7
keyless entry	7
passive arming	12
Urban cycle	154
Used engine oil	157
Using cruise control	95
Using the parking aid	93

V

Valet mode	63
deselecting	63
Vehicle alarm	155
Vehicle battery	
jump starting	
connecting cables	179
disconnecting cables	180
Vehicle battery care	178

Vehicle cleaning

alloy wheels	161
carpets and mats	163
exterior	161
interior	162, 163
parking sensors	94
rear screen	162
sunroof	162
Vehicle data recording	204
Vehicle recovery	
attaching the front tow eye	202
towing eyes	202
transporting the vehicle	202
Vehicle settings	62
valet mode	63
Video media player	
controls	121
inhibited playback	122
Voice control	123
navigation POI	124
training	124
tutorial	124
voicetags	124
Voice guidance	137
Volume	
telephone	130

W

- Warning lamps 53
 - ABS 54
 - ACC 55
 - adaptive cruise control 55
 - adaptive front lighting system 55
 - AFS 55
 - airbags 55
 - ASL (Automatic speed limiter) 55
 - audible warnings and indicators 57
 - beltminder 54
 - brake 53
 - DSC 55
 - fog lamps 55
 - headlamp high beam 56
 - indicators 56
 - lamp test 53
 - seatbelt 54
 - TPMS (Tyre pressure monitoring system) 55
- Warning symbols (battery) 178
- Warning triangle 161
- Warranty 143
- Washer jets
 - blockages 159
- Washers
 - operating 42
 - timed jet function 43
 - windscreen 43
- Washers (headlamps) 43
- Washing
 - exterior
 - paintwork 161
 - removing tar 162
 - interior
 - removing stains 163
 - polishing 162
 - removing grease 162
 - under the bonnet 162
- Water in fuel 151
- Weekly checks 155
- Weights 173
- Wheels and tyres
 - age degradation 188
 - checking the pressures after a repair . . . 148
 - flat spots 188
 - pressures 183
 - puncture repair 145
 - safety 145
 - punctured 188
 - repair kit 145, 146
 - repair procedure 147
 - safety 145
 - replacements 188
 - snow chains 190
 - TPMS (Tyre pressure monitoring system)
 - warning lamp 55
 - tyre care 182
 - valves 188
 - winter tyres 189
- Windows 44
 - anti-trap protection 45
 - one-touch operation 45
 - reset 161
 - sunroof
 - anti-trap mechanism 45
 - reset 160
- Windscreen wipers
 - speed-dependent mode 42
- Winter mode 84
- Wipers
 - drip wipe 43
 - operating 42
- Wipers and washers
 - fluid
 - specification 170
 - top up 170
 - operating 42
 - rain sensor 42
 - timed jet function 43
 - windscreen washers 43
 - wipers
 - speed-dependent mode 42

X

Xenon headlamps	
wiper detection	39

