At this point, the first time user should set up personal preferences in the **Nav set-up** area. These settings are applied whenever navigation is used.

For a short-cut to set a destination, press **Destination entry** (**3**). The Destination entry menu will be displayed after pressing **Agree** on the **CAUTION** screen.

## MAIN MENU



E141771

1. **More…**: Displays the other Nav menu screen.
2. **Cancel guidance**: Cancels current route guidance.
3. **Destination entry**: Provides a choice of options for entering a destination.
4. **Previous destination**: Displays previous destinations entered.
5. **Display/Hide POI**: Turns the POI (Point Of Interest) icons on the map on/off.

6. When a destination is set, the Jaguar logo is replaced by a soft key which enables the last voice instruction to be repeated.
7. **Route voice guidance**: Allows the voice guidance messages to be turned off for the current journey. The soft key is highlighted while voice guidance is enabled.
8. POI shortcuts: Touch icon to list available POIs close to the vehicle position.
9. **Return to map**: Advances to the main map screen.