



Rear seats

ELECTRIC SEATS

Note: This feature will not operate if the rear window isolation switch has been activated.



E134119

1. Seat back angle adjustment.
2. Lumbar support adjustment.
3. Massage OFF.
4. Massage ON, operates for 10 minutes or until switched off.
5. Front passenger seat away, forward or rearward adjustment.

To adjust the seats, the Smart Key must be in the vehicle and the ignition turned on.

REAR SEAT SAFETY

-  **Never allow passengers to travel in the luggage compartment under any circumstances.**
-  **All vehicle occupants should be seated correctly, and wear a seat belt at all times when the vehicle is in motion.**