

Fluid level checks

4. Replace filler cap.

CHECKING THE WASHER FLUID LEVEL



Do not allow screen washer fluid to come into contact with naked flames or sources of ignition.



If the vehicle is operated in temperatures below 4°C (40°F), use a washer fluid with frost protection.



Only use approved washer fluid.



Take care to avoid spillage, particularly if an undiluted or high concentration is being used. If spillage occurs, wash the affected area immediately with water.

The washer reservoir supplies the windscreen and headlamp washer jets.

Check and top-up the reservoir level at least every week, see **157, ENGINE COMPARTMENT OVERVIEW**.

Operate the washers periodically to check that the nozzles are clear and properly directed.

TOPPING UP THE WASHER FLUID

1. Clean the filler cap before opening to prevent dirt from entering the reservoir.
2. Open filler cap.
3. Top-up the reservoir with the specified washer fluid until the fluid is visible in the filler neck, see **171, LUBRICANTS AND FLUIDS**.
4. Close filler cap.