

ENGINE COMPARTMENT FUSE BOX

Fuse No	Rating (amps)	Fuse Colour	Circuit
F1	-	-	-
F2	10A	Red	DTML/Oil TMP/MAP A&B/MAF GTDI (petrol & GTDI)
	5A	Tan	EBFC, ECFC, EOTL (diesel)
F3	25A	Clear	Ignition coils (Petrol & GTDI)
	5A	Tan	PVC/MEU (diesel)
F4	30A	Green	Power wash pump.
F5	40A	Orange	EMS PWR (petrol & GTDI)
	-	-	Spare (diesel)
F6	40A	Orange	RH front screen heater and heated wiper
F7	30A	Green	TCCM (AWD)
F8	10A	Red	GPC, UHEGO
	5A	Tan	MAFA (Diesel)
F9	10A	Red	Engine cooling fan/Purge valve/CPS/ASY (petrol) Engine cooling fan/Purge valve/Waste gate/AEM (GTDI)
	5A	Tan	AEM/WIF (diesel)
F10	5A	Tan	Air conditioning
F11	-	-	-
F12	20A	Yellow	HEGO & UHEGO Bank A (petrol & GTDI)
	10A	Red	UHEG MAF A GPC (diesel)
F13	20A	Yellow	HEGO & UHEGO Bank B (petrol) Spare (GTDI)
	25A	Clear	AJDT ECM (diesel)
F14	5A	Tan	Adaptive cruise control
F15	20A	Yellow	MID bricks A&B (petrol)
	-	-	Spare (diesel & GTDI)
F16	5A	Tan	S/C Intercooler water pump coil feed (petrol)
	-	-	Spare (diesel & GTDI)
F17	5A	Tan	Pinion motor monitor
F18	15A	Blue	Horn
F19	30A	Green	Starter
F20	40A	Orange	ABS pumps