


ENGINE COMPARTMENT OVERVIEW

2.0 litre petrol engine



E144236


1. Washer fluid.
2. Brake fluid (right-hand drive vehicles).
3. Engine oil.
4. Brake fluid (left-hand drive vehicles).
5. Coolant.
6. Power steering.
7. Engine oil dipstick.



Do not drive the vehicle if there is a possibility that leaked fluid will come into contact with a hot surface, such as the exhaust.

Maintenance

3.0 and 5.0 litre petrol engines




E132956

1. Washer fluid.
2. Brake fluid (right-hand drive vehicles).
3. Engine oil (3.0L engine).
4. Engine oil (5.0L engine).
5. Brake fluid (left-hand drive vehicles).
6. Coolant (5.0L engine).
7. Engine oil dipstick (3.0L engine).
8. Power steering (5.0L engine).
9. Power steering (3.0L engine).
10. Coolant (5.0L engine).



Do not drive the vehicle if there is a possibility that leaked fluid will come into contact with a hot surface, such as the exhaust.

Diesel engine



E135275

1. Washer fluid.
2. Power steering.
3. Brake fluid (right-hand drive vehicles).
4. Engine oil.
5. Brake fluid (left-hand drive vehicles).
6. Coolant.



Do not drive the vehicle if there is a possibility that leaked fluid will come into contact with a hot surface, such as the exhaust.