

# Entering the vehicle

To stop the windows from opening/closing during the global opening/closing operation, press any of the buttons on the Smart Key or operate the driver's window switch. To stop a particular window from opening, operate the relevant window switch.

For Global closing, see **11, GLOBAL CLOSING**.

## DRIVE-AWAY LOCKING

Locks all the doors when the vehicle exceeds 8 km/h (5 mph). Use of the central locking/unlocking buttons (see **226, DRIVER CONTROLS**) will override the drive-away locking feature for the rest of a journey.

If a door is individually unlocked and opened, all doors will relock when the open door is subsequently closed.

**Note:** Drive-away locking can be enabled/disabled via the Vehicle Set-up area of the instrument panel menu.

## CONVENIENCE MODE

When the door is opened using either the Smart Key or keyless entry, the vehicle's electrical system initiates the convenience mode. The following systems become functional:

- Driver position memory.
- Seat and steering column adjustment.
- Interior and exterior lighting.
- Message centre.
- Auxiliary power socket.

## STEERING COLUMN LOCK

Your vehicle is fitted with an electronic steering column lock. The column unlocks when a Smart Key is detected inside the vehicle.

If any malfunction of the steering column lock occurs, **STEERING COLUMN LOCKED** will be displayed in the message centre. If this occurs:

1. Lock and then unlock the vehicle using the Smart Key.
2. Try again to unlock the steering column lock, by turning the steering wheel gently to the left and right whilst locking and then unlocking the vehicle using the Smart Key.
3. If the problem persists, seek qualified assistance immediately.

## REMOTE KEY FOB CARE



**To prevent accidental operation, which may result in an injury, never leave the Smart Key in the vehicle if children or animals are also left in the vehicle.**



Do not expose to extremes of heat, dust, humidity or allow contact with fluids. Do not leave the transmitter exposed to direct sunlight.

The emergency key blade number is recorded on an attached label. Peel off the label and keep it in a safe place, but not in the vehicle.

The operational range of the Smart Key will vary considerably depending on atmospheric conditions and interference from other transmitting devices.

**Note:** The radio frequency used by the Smart Key may be used by other devices (e.g. medical equipment). This may prevent the Smart Key from operating correctly.