

# Telephone

If the mobile phone supports **Bluetooth** Hands Free Profile 1.5 (HFP 1.5), additional features will be displayed on the vehicle touch screen, such as battery meter, signal strength and network operator.

**Instructional video** - Bluetooth connectivity website.



## PAIRING AND CONNECTING USING THE PHONE

*Note: The process of pairing and connecting your phone with the vehicle using the mobile phone will vary depending on the type of mobile phone used.*

1. Ensure that the touch screen is active.
2. From the **Home** menu, select **Phone**.
3. A menu will appear. Select **Search new**.
4. Select the **Device to vehicle** option.

**Note:** The vehicle's **Bluetooth®** wireless technology system is discoverable for only 3 minutes.

5. Using the mobile phone, search for **Bluetooth** devices.  
On some phones, this is referred to as new paired device. See your phone's operating instructions for further information.
6. When the vehicle's **Bluetooth** wireless technology system is discovered, follow the on-screen instructions. Select **Yes** when prompted, to confirm the pairing.  
Either the phone or the vehicle system will ask for a PIN (Personal Identification Number). When prompted, enter a PIN of your choice and select **OK** to confirm.

7. Enter the same PIN into the other device.
8. Once your phone is paired and connected to the system, a confirmation message will be displayed before switching to the **Digit Dial** screen.

**Note:** Some mobile phones require the **Bluetooth** wireless technology pairing to be set as 'authorised' or 'trusted' in order to automatically connect. Please refer to your phone's operating instructions for further information.

**Instructional video** - Pairing a Bluetooth device to the vehicle.



## PAIRING AND CONNECTING USING THE TOUCH SCREEN

1. Switch on your mobile phone's **Bluetooth®** wireless technology connection. Make sure that your mobile phone is in **Bluetooth** wireless technology discoverable mode, sometimes referred to as find me mode (see your phone's operating instructions for more information).
2. Switch the ignition on and ensure the touch screen is active.
3. From the **Home** menu select **Phone**.
4. A menu will appear. Select **Search new**.
5. Select the **Vehicle to device** option.
6. Select your phone from the displayed list and select the corresponding **Pair and connect** option.