


Stability control

CONFIGURABLE DYNAMIC MODE



149073

Vehicles with configurable dynamics, allow the dynamic mode settings to be configured via the touch screen for selected characteristics, with a choice between Normal and Dynamic settings. Touch **Extra features** on the **Home menu** screen. See **53, TOUCH SCREEN HOME MENU**.

1. Touch to display and adjust configurable settings when in Dynamic mode.
2. **Stopwatch:** Touch to display live timings and split timings.

Note: Up to 99 split times can be saved and reviewed.

Note: When the Press to split button has been pressed it is disabled for 3 seconds while the split time is displayed.

3. **G Meter:** Touch to display the current amount and direction of G Force.
4. **Pedal Graph:** Touch to display a brake and accelerator graph or a live display.
5. Indicates status, Dynamic or Normal.
6. Touch to display a description of the function.
7. **Engine:** Touch to select Dynamic or Normal setting.
8. **Steering:** Touch to select Dynamic or Normal setting.
9. **Suspension:** Touch to select Dynamic or Normal setting.
10. Displays which dynamic functions are selected.
11. **Gear Shift:** Touch to select Dynamic or Normal setting.