


To reset the seat:

1. Remove the obstruction.
2. Adjust the seat to the point where movement is restricted.
3. Press and hold the switch for at least 2 seconds to override the restriction.

Instructional video - Memory seats.



MANUAL SEATS



E149589



Do not adjust the seat while the vehicle is moving. Doing so could cause loss of vehicle control and personal injury.

1. Seat back angle adjustment.
2. Height adjustment.
3. Forward and rearward adjustment.