
To reset the seat:

- 1. Remove the obstruction.
- **2.** Adjust the seat to the point where movement is restricted.
- **3.** Press and hold the switch for at least 2 seconds to override the restriction.

Instructional video - Memory seats.



MANUAL SEATS



 Λ

Do not adjust the seat while the vehicle is moving. Doing so could cause loss of vehicle control and personal injury.

- 1. Seat back angle adjustment.
- 2. Height adjustment.
- 3. Forward and rearward adjustment.