
Storage compartments

STORAGE COMPARTMENTS



- 1. Cup holders: Press the button on the lid and release to access the cup holders.
- holders when driving.Glove box: Open using the glove box

Do not drink, or use the drinks

- release (arrowed).
- **3.** Cubby box: To raise the lid, press the button under the front lip.
- 4. Rear storage compartment: To open the lid, press the button above the storage compartment or store items behind the storage net.
- 5. Door storage.

Note: The cubby box and rear storage compartment lids may have locks which operate when the vehicle is locked/unlocked.

Only use approved accessories.

Storage compartments

Auxiliary power sockets: There are 2 auxiliary power sockets, one is located on the centre console (see **206**, **DRIVER CONTROLS**) and the other is in the cubby box.