- 4. A menu will appear. Select **Search new**.
- 5. Select the Vehicle to device option.
- Identify your device from the displayed list and select the corresponding Pair and connect option.

Note: If more than 5 devices are detected, it may be necessary to use the scroll bar to see the entire list.

- When prompted, enter the Personal Identification Number (PIN) code into your device. See your device's operating instructions for more information.
- 8. Once your device is paired and connected to the system, a confirmation message will be displayed before switching to the My music, Bluetooth® wireless technology view

Note: Due to the duration of a Bluetooth® wireless technology search, it is advised that the time-out to home screen feature is switched off before attempting to search for Bluetooth® wireless technology devices. This setting can be changed within Setup, Screen, Time out home.

LOSS OF CONNECTION

If a loss of connection between the vehicle and the **Bluetooth**® wireless technology device occurs, a pop-up is displayed. Select **Reconnect** to automatically restore the connection. A confirmation pop-up will appear before the touch screen reverts to its previous mode.

CHANGING/DISCONNECTING A DEVICE

- 1. From the My music menu, select Settings.
- 2. From the Settings menu, select Register.
- 3. Select **Disconnect**. A confirmation pop-up will appear and then you will be given the option to **Search new** or select a different device from the list of paired devices.