

4. A menu will appear. Select **Search new**.
5. Select the **Vehicle to device** option.
6. Identify your device from the displayed list and select the corresponding **Pair and connect** option.

***Note:** If more than 5 devices are detected, it may be necessary to use the scroll bar to see the entire list.*

7. When prompted, enter the Personal Identification Number (PIN) code into your device. See your device's operating instructions for more information.
8. Once your device is paired and connected to the system, a confirmation message will be displayed before switching to the **My music, Bluetooth®** wireless technology view.

***Note:** Due to the duration of a Bluetooth® wireless technology search, it is advised that the time-out to home screen feature is switched off before attempting to search for Bluetooth® wireless technology devices. This setting can be changed within **Setup, Screen, Time out home**.*

## LOSS OF CONNECTION

If a loss of connection between the vehicle and the **Bluetooth®** wireless technology device occurs, a pop-up is displayed. Select **Reconnect** to automatically restore the connection. A confirmation pop-up will appear before the touch screen reverts to its previous mode.

## CHANGING/DISCONNECTING A DEVICE

1. From the **My music** menu, select **Settings**.
2. From the **Settings** menu, select **Register**.
3. Select **Disconnect**. A confirmation pop-up will appear and then you will be given the option to **Search new** or select a different device from the list of paired devices.