
Front seats

ELECTRIC SEATS



1. Cushion length adjustment.

- 2. Bolster adjustment:
 - Bolster inflate.
 - Bolster deflate.

- 3. Lumbar support adjustment.
- 4. Seat back angle adjustment.
- **5.** Head restraint height adjustment.
- **6.** Height adjustment.
- 7. Forward and rearward adjustment.
- 8. Cushion front tilt adjustment.

To adjust the seats, the Smart key must be in the vehicle and the ignition turned on.

If an obstruction is encountered while the seat is in motion, the seat will stop moving and further movement will be restricted until reset.

To reset the seat:

- 1. Remove the obstruction.
- **2.** Adjust the seat to the point where movement is restricted.
- **3.** Press and hold the switch for at least 2 seconds to override the restriction