

## **TOWING EYES**





E143964



The towing eyes at the front and rear of the vehicle are designed for on-road recovery only.



Do not tow the vehicle on all four wheels.

## ATTACHING THE FRONT TOWING EYE

The front towing eye is included in the tool kit, located in the under-floor area of the luggage compartment.

- 1. Pop out the cover in the front bumper.
- 2. Locate the towing eye through the bumper and screw the towing eye counter clockwise into its fixing, until secure.
- 3. Rear towing eye.

## TRANSPORTING THE VEHICLE

- Only use the lashing points indicated, or over-wheel lashings or wheel chocks.
  Use of any other lashing position may cause damage to the vehicle.
- During vehicle recovery, to make sure the steering column remains unlocked, make sure the Smart key remains in the vehicle, the rotary drive selector is in N (Neutral) and the ignition is on.

**Note:** Do not attach or apply any loads to the rear spoiler (for example bicycle carrier, luggage rack, signs, towing equipment, etc.).

The recommended method for recovery/ transportation of the vehicle, is on a transporter or trailer designed for that purpose.

Make sure that transportation is carried out by suitably qualified persons and that the vehicle is secured correctly.