

DECLARATIONS OF CONFORMITY

SIEMENS VDO
AUTOMOTIVE

Siemens VDO Automotive AG P.O. Box 10 09 43 D-93009 Regensburg

Name: Regine Quastner
 Department: SV C BC P2 RF TG
 Tel.: +49(0)941/790-3554
 Fax: +49(0)941/790-3554
 E-Mail: Regine.Quastner@siemens.com
 Internet: www.siemensvdo.de
 Our Ref.: Doc. 5Wk48955.606
 Date: 16/12/2003

Declaration of Conformity in accordance with Directive 1999/5/EC (R&TTE Directive)

Manufacturer: Siemens VDO Automotive AG
 Body & Chassis Electronics

Address: Dep. SV C BC P2 RF TG
 Siemensstrasse 12
 D-93009 Regensburg
 Germany

Product type designation: 5Wk4 8956

Intended use: Radio frequency transmitter used in vehicle locking/unlocking systems
 The product mentioned above complies with the essential requirements and other relevant provisions of Directive 1999/5/EC, when used for its intended purpose.

Health and safety pursuant to § 3.1.1.a: Applied standard(s):
 EN 60950; 2000

Electromagnetic compatibility pursuant to § 3.1.b: Applied standard(s):
 EN 301 489-01, -3, V.1.4.1 (2002-08)

Efficient use of spectrum pursuant to § 3.2: Applied standard(s):
 EN 300 220 -1; V.1.3.1 (2000-09)

The following marking applies to the above mentioned product:



Siemens VDO Automotive AG
 Regensburg, 2003-12-16

J. Tarabilla
 Jean-François Tarabilla
 Executive Vice President
 Body & Chassis Electronics
 Operations

Siemens VDO Automotive AG Body & Chassis Electronics
 Postal Address: Siemens VDO Automotive AG
 P.O. Box 10 09 43
 D-93009 Regensburg
 Germany
 Helmut Müller
 Rainer Müller
 Office Address: Siemensstrasse 12
 D-93009 Regensburg
 Tel.: +49(0)941/790-3
 Fax: +49(0)941/790-3

Siemens VDO Automotive AG, Chairman of the Supervisory Board: Bernd G. Volzke, Managing Board: Franz Wenzel, Chairman: Wolfgang Klaus Eger
 Sole Representative: Jürgen Eiler, Registered Office: Regensburg, Commercial Registry: Regensburg, HRB 15307

Page 1 of 2

SIEMENS VDO
AUTOMOTIVE

Siemens VDO Automotive AG P.O. Box 10 09 43 D-93009 Regensburg

Name: Schneider Tania
 Department: SV C BC P2 RF TG
 Phone: +49(0)941/790-6622
 Fax: +49(0)941/790-13922
 E-Mail: tania.schneider@siemens.com
 Internet: www.siemensvdo.de
 Your Letter: Doc. 5Wk45693.doc
 Our Ref.: 18.01.2006
 Date:

Declaration of Conformity

We, the undersigned, declare that

the transmitter 5Wk45693 uses the same schematic, layout and pcb as transmitter 5Wk4 9556.

They only differ in:

Capacitor C301, 680pF/2% was changed to capacitor C311, 680pF/2%
 Resistor R302, 18kOhm was changed to resistor R322, 33kOhm.
 Capacitor C103, 10nF was changed to capacitor C103, 22nF.

These modifications were necessary to adapt several car lines.

These modifications do not influence the RF characteristics of the transmitter.

Yours truly,

Siemens VDO Automotive AG
 Regensburg, 18.01.2006

H. M. Müller
 Helmut Müller
 Executive Vice President & CEO
 Body and Chassis Electronics

Siemens VDO Automotive AG Body & Chassis Electronics
 Postal Address: Siemens VDO Automotive AG
 P.O. Box 10 09 43
 D-93009 Regensburg
 Germany
 Helmut Müller
 Rainer Müller
 Office Address: Siemensstrasse 12
 D-93009 Regensburg
 Tel.: +49(0)941/790-3
 Fax: +49(0)941/790-3

Siemens VDO Automotive AG, Chairman of the Supervisory Board: Bernd G. Volzke, Managing Board: Franz Wenzel, Chairman: Wolfgang Klaus Eger
 Sole Representative: Jürgen Eiler, Registered Office: Regensburg, Commercial Registry: Regensburg, HRB 15307

Page 1 of 1

SIEMENS VDO

A U T O M O T I V E

Copyright © 2006 by John Wiley & Sons, Inc.

Name	Dagmar Kolar
Department	SV/CTS REG EMC Laboratory
Tel.	+49(0)941/790-6899
Fax	+49(0)941/790-6890
E-Mail	dagmar.kolar@siemens.com
Internet	www.siemensvto.de
Our Ref.	Doc_SWK49090.doc
Date	03/08/2005

Declaration of Conformity in accordance with Directive 1999/5/EC (R&TTE Directive)

Manufacturer: Siemens VDO Automotive AG
Body & Chassis Electronics

Address: Dep. SV C BC P2 RF TG
Siemenstrasse 12
D-93049 Regensburg

Product type designation: 5WK4 9096

Radio frequency receiver used in vehicle locking/unlocking systems

Intended use:

The product mentioned above complies with the essential requirements and other relevant provisions of Directive 1999/5/EC, when used for its intended purpose:

Health and safety pursuant to §3.1.a:
Applied standard(s):
EN 60950:2000

Electromagnetic compatibility pursuant to § 3.1.b:	Applied standard(s): EN 301 489-1,-3; V1.4.1 (2002-08)
Efficient use of spectrum pursuant to § 3.2:	Applied standard(s): EN 300 220-1; V1.3.1 (2000-09)

The following marking applies to the above mentioned product:

Siemens VDO Automotive AG
Regensburg, 2005-08-03

J. V. Tarabba
Jean-Francois Tarabba
Executive Vice President
Body and Chassis Electronics Operations

Siemens VDO Automotive AG

Helmuth Matschke

Office Address:
Sennaribasa 12
D-63055 Regensburg
Tel. +49(0)941/7903

Siemens AG Chairman of the Supervisory Board: Ewald G. Kusch, Managing Board: Franz Wessing, Chairman: Hans Eppel, General Management, 20000 Litter, Registered Office: Munich, Commercial Registry: Munich, HRB 152327

Page 1 of 1

SIEMENS VDO

Siemens VDO Automotive

Name	Kolar Dignair
Department	SV C S HBG 42
Phone	+49 941 790-8999
Fax	+49 941 790-136609
Mobile	
E-Mail	dignair.kolar@siemens.com
Internet	www.siemensvdo.com
Your letter of Our Reference Date	Doc_5WK49243.doc 10. Nov. 2006

Declaration of Conformity in accordance with Directive 1999/5/EC (R&TTE Directive)

Manufacturer: Siemens AG
Siemens VDO Automotive
Body & Chassis Electronics

Address: Siemensstrasse 12
D-93055 Regensburg
Germany

Product type designation:

Radio frequency transmitter used in vehicle locking/unlocking systems

Health and safety pursuant to §3, 1.a:
Applied standard(s):
EN 60950: 2001

Electromagnetic compatibility pursuant to § 3.1.b	Applied standard(s)
	EN 301 489 -01: V1.6.1 (2005-09)
	EN 301 489 -03: V1.4.1 (2002-08)

Efficient use of spectrum pursuant to § 3.2:
Applied standard(s):
EN 300 220 -1: V1.3.

The following marking applies to the above mentioned product:

Siemens AG
CE

Klaus Müller
Executive Vice President & CFO
Interior Controls

Siemens AG
Division Body & Chassis Electronics
Postfach 10 08 40
90026 Erlangen, Germany

Carsten Alldorf-Gibbsch: Chairman of the Supervisory Board Heinrich v. Pörr; Managing Board Klaus Dinkelhoff, Chairman and Chief Executive Officer, Johannes Füllendorf, Thomas Gaiswieser, Jörg Kasper, Edward G. Krüskamp, Rüd Langewitz, Eduardo Morales, Jürgen Rademacher, Ralf R. Reinhardt, Hermann Reuscher, Axel J. Stank, Klaus Weyrich, Klaus Wüstenberg.
Integrated Office, Berlin and Münster, Commercial register: Berlin Odaanstraße, 10107 1200, Münster, 48109 6694.

Page 7 of 7

i.v. the Field
Dr. Martin Fischer
/ice President
Wireless Products and Modules

Office Address:
Siemensstrasse 12
D-93059 Regensburg
Tel. +49(0)941/790-3

Frank Weising, Chairman. Members: Klaus Eggert,
5637

Page 1 of 1

EC-Declaration of Conformity**Manufacturer:** _____

Valco Raytheon Systems, Inc.

Address(es): _____

EU: Lahmstrasse 12, 74321 Bietigheim-Bissingen, Germany

(USA: 150 Stephenson Highway, Troy, MI 48063 USA)

Declares that the product:**type:** _____

MultiBeam Radar 24GHz

model: _____

MBR Gen2

Intended use: _____

Blind Spot Detection

complies with the essential requirements of Article 3 of the R&TTE 1999/SEC Directive, if used for its intended use and that the following standards has been applied:

1 Health (Article 3.1 of the R&TTE-Directive)

Applied Standard

EN 50385

Issue

2002

2 Safety (Article 3.1 of the R&TTE-Directive)

Applied Standard

EN 60950-1

Issue

2006

3 Electromagnetic Compatibility (Article 3.1.b of the R&TTE-Directive)

Applied Standard

ETSI EN 301 489-1

Issue

V1.6.1

ETSI EN 301 489-3

Issue

V1.4.1

4 Efficient Use of the radio frequency spectrum (3.2 of the R&TTE-Directive)

Applied Standard

ETSI EN 300 440-1

Issue

V1.3.1

ETSI EN 300 440-2

Issue

V1.1.2

10/10/2007

Eric Amiot



(Place and date of the declaration of conformity)

(Name and signature)

A

ABS (Anti-lock braking system)	
warning lamp	59
ACC (Adaptive cruise control)	97
automatic switch-off	99
driving hints	99
fault	100
follow mode	97
gap change	98
low speed switch-off	99
malfunction	100
operating	97
override	98
resume follow mode	99
resume set speed	99
warning lamp	60
Active differential control	89
Adaptive front lighting system (AFS)	
warning lamp	60
AFS (Adaptive front lighting system)	43
After a collision	
pedestrian protection system	201
Age degradation (tyres)	185
Air conditioning	
air quality sensor	70
Air quality sensor	70
Airbags	
module covers	162
SRS (Supplementary restraint system)	152
warning lamps	60
Alarm	14, 152
automatic relocking and arming	15
battery backed sounder	15
deactivating	15
passive arming	15
perimeter	14
sensor fault	15
tilt sensor	15
Anchor points (luggage)	72
Antifreeze level check	165
Anti-theft system	152
Anti-trap mechanism	
sunroof	50

Anti-trap protection	
windows	50
Approach lamps	43
Arduous driving conditions	153
ASL (Automatic speed limiter)	
warning lamp	60
Audible warnings	61
Audio	
Settings	105
Audio system	162
Audio/video	
controls	104
portable media	
connections	116
controls	114
pairing	118
play	117
television	
controls	120
video media player	
controls	122
Automatic gearbox	85
Automatic locking	7
Automatic switch off (ACC)	99
Auxiliary devices	
connecting multiple devices	118

B

Battery	
care	169
changing	
timed climate remote	171
charging	171
jump starting	
connecting cables	170
disconnecting cables	171
monitoring system	170
warning symbols	169
Battery backed sounder	15
Beltminder	
warning lamp	58

Index

- Belts 162
 - seatbelt warning lamp 58
- Bluetooth 127
 - audio
 - pairing 118
 - media
 - pairing 118
 - telephone
 - compatibility 127
 - icons 129
 - overview 126
 - pairing 128
 - phonebook 130
 - safety 127
- Bonnet
 - closing 154
 - opening 154
- Boost starting 170, 171
- Brakes
 - ABS warning lamp 59
 - advanced emergency assist 101
 - EBA (Emergency brake assist) 92
 - EBD (Electronic brake force distribution) 92
 - ESS (Emergency stop signal) 93
 - hill start assist 92
 - pedal travel 207
 - warning lamp 58
- BSM (Blind spot monitor) 53
- Bulbs
 - license plate 158
 - number plate 158
- C**
- Call volume 129
- Capacities 205
- Carpets and mats 162
- Car-wash 160
- Changing a fuse 172
- Changing the battery (timed climate) ... 171
- Charging the vehicle battery 171
- Cleaning
 - alloy wheels 160
 - carpets and mats 162
 - exterior 160
 - paintwork 160
 - glass 160
 - interior 161, 162
 - leather 161
 - parking sensors 95
 - polishing 161
 - rear screen 161
 - removing grease 161
 - removing stains 162
 - removing tar 161
 - sunroof 161
 - under bonnet 160
 - using a car-wash 160
- Climate seats 70
- Clock 162
- Closing
 - alarm sensor faults 15
 - single locking 13
- Closing the bonnet 154
- Condensation (headlamps) 44
- Conformity declarations 144, 211
- Consumption (fuel) 150
 - urban cycle 151
- Controls
 - headlamps 42
- Coolant
 - checking the level 165
 - specification 165
 - top up 165
- Cruise control
 - ACC (Adaptive cruise control) 97
 - low speed switch-off 99
 - malfunction 100
 - operating 97
 - override 98
 - resume follow mode 99
 - resume set speed 99
 - follow mode 97
 - operating 96

D

DAB	
ensembles	113
DAB radio	
controls	111
Daily checks	152
Data recording	201, 202
Daylight running lamps	43
Dealer locations	139
Declarations of conformity	211
navigation system	144
Derv	
sulphur content	146
Deselecting valet mode	67
Destination entry	135
postcode	138
search area	135
Detection beam issues	100
Diesel	
engine	146, 147
switching off	81
filler flap	147, 148
fuel consumption	150
misfuelling device	148
specification	149
sulphur content	146
water in fuel	146
Diesel particulate filter (DPF)	153
Differential control	89
Dimensions	208
Direction indicators	43
warning lamp	60
Disability modifications	152
Door transceiver	
entry gate	57
garage door opener	55
programming	55
programming a single button	56
rolling code device programming	56
Double locking	13
DPF (Diesel particulate filter)	153
Drive away locking	7

Drive control	
operation	90
Driver information module	
warning lamps	58
Driving	
ACC (Adaptive cruise control)	97, 99
override	98
adaptive cruise control	
automatic switch off	99
arduous conditions	153
before starting	201
daily checks	152
DSC warning lamp	
active	59
off	59
dynamic mode	88
EBA (Emergency brake assist)	92
EBD (Electronic brake force	
distribution)	92
forward alert	101
mirror dip when reversing	52
sitting correctly	19
wipers	
rain sensor	47
Driving abroad	
headlamps	44
DSC (Dynamic stability control)	
switching between DSC and tracDSC	89
switching off	88
switching on	89
warning lamp	
active	59
off	59
Dynamic mode	88

E

EBA (Emergency brake assist)	92
EBD (Electronic brake force distribution)	92
Electric seats	
front	16
Electronic brake force distribution (EBD)	92
Electronic data	202

Index

Electronic parking brake (EPB)	92
Emergency	
jump starting	
connecting cables	170
disconnecting cables	171
Emergency brake assist (EBA)	101
Engine	
compartment	
cleaning	160
fuse box	173
opening	154
overview	155
coolant level checking	165
diesel	146, 147
DPF (Diesel particulate filter)	153
engine compartment	155
failure to start	82
oil level check	163
specifications	203
switching off	81
Ensembles (DAB radio)	113
Entering a destination	135
Entering the vehicle	
entry and exit mode	27
keyless entry	6
Entertainment	
DAB radio	
controls	111
portable media	
changing device	119
connecting devices	117
connecting multiple devices	118
connections	116
controls	114
lost connection	119
pairing	118
playing	117
radio	
controls	109
RDS (Radio data system)	110
RSE (Rear screen entertainment)	
screen settings	65

telephone	
pairing	128
phonebook	130
television	
controls	120
touch screen	162
home menu	64
operating	65
setup	65
system settings	65
touch screen care	65
video media player	
controls	122
Entry and exit mode	27
EPB (Electric parking brake)	92
Ethanol	145
EU conformity (navigation system)	144
Event data recording	202
Exiting the vehicle	
door locks and release levers	13
global closing	14
keyless locking	14
Exterior cleaning	160
Exterior mirrors	51
Extinguisher	159

F

Faulty alarm sensors	15
Fire extinguisher	159
First aid kit	159
Flat spots	185
Fluids	
capacities	205
coolant	
specification	165
top up	165
engine oil	
check	163
fuel tank capacity	149
power steering	
check	167
specification	167

specifications	204
washer	
specification	168
top up	168
Fog lamps	
warning lamp	59
Follow mode	
entering	97
gap change	98
override	98
resume	99
Forward alert	101
Front parking aid	94
system fault	95
Fuel and refuelling	
consumption	150
extra-urban cycle	151
urban cycle	151
diesel	146
sulphur content	146
ethanol	145
filler flap	147, 148
fuel consumption	
urban cycle	151
fuel specification	149
fuel system	154
methanol	145
misfuel device	148
MTBE (Methyl tertiary butyl ether)	146
octane rating	145
running out	146
safety precautions	145
tank capacity	149
water in fuel	146
Fuses	
changing	172
engine compartment fuse box	173
locations	172
luggage compartment fuse box	176
Passenger compartment fuse box	175

G

Garage door opener	55
entry gate	57
erase all programming	56
programming	55
a single button	56
rolling code device	56
Gear selector	86
Gearbox	
automatic	85
limp home mode	87
operation	90
selector	86
temporary manual selection	86
winter mode	88
Glass cleaning	160
Global closing	14
Global opening	6

H

Handling	
DSC warning lamp	
active	59
off	59
dynamic mode	88
EBD (Electronic brake force distribution)	92
Head restraints	25
manual	25
Headlamps	
adaptive	43
AFS (Adaptive front lighting system)	43
approach lamps	43
condensation	44
controls	42
daylight running lamps	43
driving abroad	44
high beam warning lamp	60
warning lamp (AFS)	60
washers	48
wiper detection	43
Heated seats	70

Index

Heated steering wheel	27
High beam	
warning lamp	60
Hill start assist.	92
Homelink	55
programming a single button	56
rolling code device programming	56

I

Ignition	
rolling re-start	82
switching on	81
Indicators	43
warning lamp	60
Infotainment	
DAB radio	
controls	111
portable media	
changing device	119
connecting devices	117
connecting multiple devices	118
connections	116
controls	114
lost connection	119
pairing	118
playing	117
radio	
controls	109
RDS (Radio data system)	110
RSE (Rear seat entertainment)	
screen settings	65
telephone	
pairing	128
phonebook	130
television	
controls	120
touch screen	162
home menu	64
operating	65
setup	65
system settings	65
touch screen care	65

video media player	
controls	122
Inhibited media playback	123
Instrument pack	162
Instrument panel	
lamp test	58
warning lamps	58
Interior cleaning	161, 162
carpets and mats	162

J

Jaguardrive control	
operation	90
Jump starting	170, 171

K

Keyless entry	6
Keyless locking	14
Keys	
single locking	13

L

Lamp test	58
Lamps	
condensation	44
controls	42
warning lamps	58
wiper detection	43
Leather cleaning	161
License plate bulb	158
Lights	
condensation	44
controls	42
Limp home mode	87
Load securing	72
Locking	
alarm sensor faults	15
automatic relocking	15
confirmation	13
door locks and release levers	13
double locking	13
drive away	7

global closing	14	disconnecting cables	171
keyless	14	leather cleaning	161
mislock	13	lubricants and fluid specifications	204
Locking and unlocking		number plate bulb	158
alarm		paintwork repair	160
perimeter	14	smart key battery changing	11
sensor faults	15	sunroof wind deflector	161
passive arming	15	weekly checks	152
single locking	13	Manual head restraints	25
unlocking	4	Map (navigation system)	138
Lubricants		Media	123
specifications	204	inhibited	123
Luggage		portable	
anchor points	72	lost connection	119
Luggage compartment		play	117
fuse box	176	portable media	
		connections	116
M		Memory seats	
Maintenance		recalling a position	19
blocked washer jets	158	Methanol	145
capacities	205	Minor paintwork damage repair	160
changing a fuse	172	Mirrors	
checking the tyre pressures after a		BSM (Blind spot monitor)	53
repair	193	dip when reversing	52
cleaning		Mirrors and windows	
polishing	161	exterior mirrors	51
removing grease and tar	161	sunroof	
removing stains	162	anti-trap mechanism	50
cleaning alloy wheels	160	reset	159
cleaning glass	160	Misfuelling device	148
cleaning parking sensors	95	Modifications for disabilities	152
cleaning rear screen	161	Monitoring system (battery)	170
closing the bonnet	154	Moon roof	
coolant level checking	165	anti-trap mechanism	50
daily checks	152	reset	159
DPF	153	mpg	150
engine compartment	155	MTBE (Methyl tertiary butyl ether)	146
exterior cleaning	160		
fuse box (luggage compartment)	176		
interior cleaning	161, 162		
jump starting			
connecting cables	170		

Index

N

Navigation

avoid points	136
cancel guidance	137
destination entry	135
coordinates	138
emergency	138
motorway	138
postcode	138
previous	138
search area	135
start guidance	136
easy route	136
favourites	137
home location	137
learn route	137
map	138
map auto zoom	135
map split screen	134
menu	133
operating	132
overview	131
POI (Points of interest)	139
categories/sub-categories	139
quick POI selection	137
POI search	139
restore defaults	137
screen modes	135
TMC	140
display	140
icons	140
using TMC	141
voice commands (POI)	125
voice guidance	137
Number plate bulb	158

O

Occupant safety

seatbelts	162
warning lamp	58

Oil

engine

level check	163
oil specification	164
used engine oil	154
One-touch operation (windows)	50
Opening	
alarm sensor faults	15
bonnet	154
Overriding speed and follow mode (cruise)	98

P

Paddle shift

temporary manual selection	86
--------------------------------------	----

Paintwork

cleaning	160
repair	160

Parking aid

operating	94
sensor cleaning	95
system fault	95

Parking brake

	92
--	----

Passenger compartment fuse box

	175
--	-----

Passive arming

	15
--	----

Pedestrian protection system

after deployment	201
----------------------------	-----

Perimeter alarm

	14
--	----

Petrol

consumption	150
engine	
switching off	81
filler flap	147, 148
octane rating	145
specification	149

Phone

bluetooth	127
call volume	129
changing connected phone	129
compatibility	127
controls	
steering wheel	129
icons	129

overview	126	RDS-TMC	140, 141
pairing using touch screen	128	display	140
phonebook	130	icons	140
safety	127	Rear media	
POI (Points of interest)	139	screen settings	65
search	139	Rear screen cleaning	161
Portable media		Recalling seat memory position	19
changing device	119	Recording	
connecting devices	117	service data	201
connecting multiple devices	118	Recovery	
connections	116	towing eyes	199
controls	114	transporting	199
lost connection	119	Refuelling	
pairing	118	diesel	146
playing	117	sulphur content	146
Power steering		octane rating	145
fluid		running out of fuel	146
check	167	safety precautions	145
specification	167	Remote control	
Pressures		battery changing	11
checking		care	11
after a repair	193	system transmitters	210
tyres	180	Repairing paintwork damage	160
Previous destination (navigation system)	138	Replacement tyres	184
Programming		Resetting the windows	159
garage door opener	55	Restarting the engine while moving	82
erase all	56	Restore default settings (navigation system)	137
Puncture repair kit	190	Resume speed and follow mode (ACC)	99
instructions for use	192	Reverse parking aid	94
repair procedure	192	system fault	95
safety	190	Rolling re-start	82
Punctured tyres	184	RSE (Rear seat entertainment)	
		screen settings	65
		Running out of fuel	146
R			
Radio		S	
controls	109	Safety	
DAB ensembles	113	fuel and refuelling	145
RDS (Radio data system)	110	in the garage	153
Rain sensor	47	seatbelts	162
RDS (Radio data system)	110	warning lamp	58

Index

sitting correctly	19	manual head restraints	25
tyre care	179	memory	
used engine oil	154	recalling a position	19
using the telephone	127	rear seat safety	21
warning triangle	159	seatbelts	162
Satellite navigation		warning lamp	58
cancel guidance	137	sitting correctly	19
destination entry	135	Securing luggage	72
coordinates	138	Security	14
postcode	138	alarm	152
previous	138	passive arming	15
search area	135	perimeter	14
start guidance	136	tilt sensor	15
emergency	138	automatic relocking and arming	15
map	138	battery backed sounder	15
map split screen	134	deactivating the alarm	15
menu	133	lock confirmation	13
motorway	138	sensor faults	15
operating	132	Selecting valet mode	67
overview	131	Sensors	
POI (Points of interest)	139	security sensor faults	15
categories	139	Servicing	
quick POI selection	137	data recording	201
POI search	139	Setting a destination (navigation)	135
restore defaults	137	Settings	
screen modes	135	rear media	65
TMC	140	vehicle	66
display	140	Silencing the alarm	15
icons	140	Sitting correctly	19
using TMC	141	Smart key	
voice commands (POI)	125	battery changing	11
voice guidance	137	care	11
Screen modes (navigation system)	135	single locking	13
Search area (navigation system)	135	transmitters	210
Seatbelts	162	Snow chains	187
beltminder warning lamp	58	Specifications	
warning lamp	58	brake pedal travel	207
Seats		dimensions	208
climate	70	engine	203
electric		ethanol	145
front	16	fluids	204
head restraints	25	washer	168
heated	70	fuel	149

fuel tank capacity	149
lubricants	204
methanol	145
weight	206
Speed-dependent wipers	47
Split screen map	134
SRS (Supplementary restraint system)	
airbag covers	162
airbag warning lamp	60
airbags	152
seatbelts (beltminder) warning lamp	58
Stability control	
switching between DSC and tracDSC	89
switching off	88
switching on	89
tracDSC	89
switching between tracDSC and DSC	89
Starting	
preparation	201
Starting navigation guidance	136
Steering wheel	
adjusting	27
controls	
connect phone call	129
decrease volume	129
disconnect phone call	129
increase volume	129
scroll/search down	129
voice control talk	129
heated	27
Steering wheel controls	129
Storage compartments	79
cup holders	79
front cubby box	79
glove box	79
rear armrest	79
Sunroof	
anti-trap mechanism	50
reset	159
Switching off the engine	81
Switching on the ignition	81

T

Technical specifications	
weights	206
Telephone	
bluetooth	127
call volume	129
changing the connected telephone	129
compatibility	127
controls	
steering wheel	129
icons	129
overview	126
pairing	128
phonebook	130
safety	127
Television	
controls	120
Tilt sensor	15
Timed jet function	47
TMC (Traffic message channel)	141
display	140
icons	140
overview	140
Touch screen	162
home menu	64
navigation	
menu	133
motorway	138
POI (Points of interest)	137
postcode	138
screen modes	135
operating	65
portable media	
changing device	119
connecting devices	117
connecting multiple devices	118
connections	116
controls	114
lost connection	119
pairing	118
playing	117
RSE (Rear seat entertainment)	
screen settings	65

Index

setup	65	age degradation	185
system settings	65	flat spots	185
telephone		pressures	180
pairing	128	punctured	184
phonebook	130	repair kit	190, 192
television		repair procedure	192
controls	120	safety	190
touch screen care	65	replacements	184
valet mode	67	snow chains	187
vehicle settings	66	TPMS (Tyre pressure monitoring system)	
video media player		warning lamp	60
controls	122	tyre care	179
Tow eye (front)	199	valves	184
Towing eyes	199	warning lamp	60
TPMS (Tyre pressure monitoring system)		tracDSC	89
tyre care	179	switching between DSC and tracDSC . .	89
valves	184	Traction control	
warning lamp	60	switching between DSC and tracDSC . .	89
tracDSC	89	switching off	88
switching between DSC and tracDSC . .	89	switching on	89
Traction control		tracDSC	89
switching between DSC and tracDSC . .	89	switching between tracDSC and DSC .	89
Transmission		Transmitters	
gear selector	86	smart key	210
limp home mode	87	Transporting the vehicle	199
operation	90	Trim	
temporary manual selection	86	airbag covers (cleaning)	162
winter mode	88	TV controls	120
Transmission (automatic)	85	Tyre pressure checking after repair	193
Transmitters		Tyre repair kit	
smart key	210	repair procedure	192
Transporting the vehicle	199	Tyres	
Trim		age degradation	185
airbag covers (cleaning)	162	flat spots	185
TV controls	120	pressures	180
Tyre pressure checking after repair	193	punctured	184
Tyre repair kit		repair kit	190, 192
repair procedure	192	repair procedure	192
Tyres		safety	190
age degradation	185	replacements	184
flat spots	185	snow chains	187
pressures	180	TPMS (Tyre pressure monitoring system)	
punctured	184	warning lamp	60
repair kit	190, 192	tyre care	179
repair procedure	192	valves	184
safety	190	winter	186
replacements	184		
snow chains	187		
TPMS (Tyre pressure monitoring system)			
warning lamp	60		
tyre care	179		
valves	184		
warning lamp	60		
tracDSC	89		
switching between DSC and tracDSC . .	89		
Traction control			
switching between DSC and tracDSC . .	89		
switching off	88		
switching on	89		
tracDSC	89		
switching between tracDSC and DSC .	89		
Transmitters			
smart key	210		
Transporting the vehicle	199		
Trim			
airbag covers (cleaning)	162		
TV controls	120		
Tyre pressure checking after repair	193		
Tyre repair kit			
repair procedure	192		
Tyres			
age degradation	185		
flat spots	185		
pressures	180		
punctured	184		
repair kit	190, 192		
repair procedure	192		
safety	190		
replacements	184		
snow chains	187		
TPMS (Tyre pressure monitoring system)			
warning lamp	60		
tyre care	179		
valves	184		
winter	186		

U

Under bonnet cleaning	160
Unlocking	4, 13
alarm sensor faults	15
entry and exit mode	27
global opening	6
keyless entry	6
passive arming	15
Urban cycle	151
Used engine oil	154
Using cruise control	96
Using the parking aid	94

V

Valet mode	67
deselecting	67
Vehicle alarm	152
Vehicle battery	
jump starting	
connecting cables	170
disconnecting cables	171
Vehicle battery care	169
Vehicle cleaning	
alloy wheels	160
carpets and mats	162
exterior	160
interior	161, 162

parking sensors	95
rear screen	161
sunroof	161
Vehicle data recording	202
Vehicle recovery	
attaching the front tow eye	199
towing eyes	199
transporting the vehicle	199
Vehicle settings	66
valet mode	67
Video media player	
controls	122
inhibited playback	123
Voice control	124
navigation POI	125
training	125
tutorial	124
voicetags	125
Voice guidance	137
Volume	
telephone	129

W

Warning lamps	58
ABS	59
ACC	60
adaptive cruise control	60
adaptive front lighting system	60
AFS	60
airbags	60
ASL (Automatic speed limiter)	60
audible warnings and indicators	61
beltminder	58
brake	58
DSC	59
fog lamps	59
headlamp high beam	60
indicators	60
lamp test	58
seatbelt	58
TPMS (Tyre pressure monitoring system)	60

Warning symbols (battery)	169
Warning triangle	159
Warranty	143
Washer jets	
blockages	158
Washers	
operating	46
timed jet function	47
windscreen	47
Washers (headlamps)	48
Washing	
exterior	
paintwork	160
removing tar	161
interior	
removing stains	162
polishing	161
removing grease	161
under the bonnet	160
Water in fuel	146
Weekly checks	152
Weights	206
Wheels and tyres	
age degradation	185
checking the pressures after a repair	193
flat spots	185
pressures	180
puncture repair	190
safety	190
punctured	184
repair kit	190, 192
repair procedure	192
safety	190
replacements	184
snow chains	187
TPMS (Tyre pressure monitoring system)	
warning lamp	60
tyre care	179
valves	184
winter tyres	186

Index

Windows	49
anti-trap protection	50
one-touch operation	50
reset	159
sunroof	
anti-trap mechanism	50
reset	159
Windscreen wipers	
speed-dependent mode	47
Winter mode	88
Wipers	
drip wipe	47
operating	46
Wipers and washers	
fluid	
specification	168
top up	168
operating	46
rain sensor	47
timed jet function	47
windscreen washers	47
wipers	
speed-dependent mode	47

X

Xenon headlamps	
wiper detection	43

