Mirrors

MIRROR DIP WHEN REVERSING

The mirrors can be configured so that when Reverse (**R**) gear is selected, the passenger door mirror automatically adjusts to provide an improved viewing angle for reversing.

The exact dipped position can be adjusted using the joystick control, when the mirror is dipped. The next time **R** is selected, the newly adjusted position will be selected.

When the gear selector is moved out of ${\bf R}$, or if the vehicle's speed exceeds 12 km/h (7.5 mph) while reversing, the mirror will return to its previous position.

Mirror dip can be enabled/disabled using the touch screen, as follows:

- From the touch screen **Home** menu, select **Setup**.
- Select Security/Vehicle.
- Select Windows/mirrors.
- Select Exterior mirror dip when reversing.
- Select On or Off.