


ENGINE COMPARTMENT OVERVIEW



Do not drive the vehicle if there is a possibility that leaked fluid will come into contact with a hot surface, such as the exhaust.

2.0L petrol engine




E147394

1. Washer fluid.
2. Brake fluid:
 - A. Right hand drive vehicles.
 - B. Left hand drive vehicles.
3. Engine oil.
4. Power steering.
5. Coolant.
6. Engine oil dipstick.


Maintenance

3.0L and 2.2L diesel engines



1. Washer fluid.
2. Brake fluid:
 - A. Right hand drive vehicles.
 - B. Left hand drive vehicles.
3. Engine oil (3.0L).
4. Engine oil (2.2L).
5. Power steering (2.2L).
6. Coolant (2.2L).
7. Coolant (3.0L).
8. Power steering (3.0L).

5.0L and 3.0L petrol engines



E143959

1. Washer fluid.
2. Brake fluid:
 - A. Right hand drive vehicles.
 - B. Left hand drive vehicles.
3. Engine oil.
4. Coolant (5.0L).
5. Power steering:
 - A. 5.0L.
 - B. 3.0L.
6. Coolant (3.0L).