

## ENGINE COMPARTMENT FUSE BOX

Fuse No	Rating (amps)	Fuse Colour	Circuit
F1	40A	Orange	Petrol PCM.
F2	-	-	-
F3	-	-	-
F4	-	-	-
F5	40A	Orange	ABS pump.
F6	30A	Green	Power wash pump.
F7	50A	Red	Cigar lighter.
F8	30A	Green	All wheel drive.
F9	50A	Red	Engine management system.
F10	-	-	-
F11	-	-	-
F12	-	-	-
F13	30A	Green	Wipers.
F14	30A	Green	Starter solenoid.
F15	40A	Orange	Front screen heater - LH.
F16	40A	Orange	Front screen heater - RH.
F17	-	-	-
F18	60A	Aqua	Glow plugs (diesel only).
F19	5A	Tan	Adaptive cruise control. FLS.
F20	15A	Blue	Horn.
F21	25A	Clear	ABS valves.
F22	-	-	-
F23	5A	Tan	STR monitor.
F24	-	-	-
F25	10A	Red	ABS.
F26	10A	Red	Engine management system, ECM, Transmission control module.
F27	5A	Tan	Secondary air injection.
F28	5A	Tan	Adaptive front lighting - LH.
F29	5A	Tan	Adaptive front lighting - RH.

# Fuses

Fuse No	Rating (amps)	Fuse Colour	Circuit
F30	20A	Yellow	HEGO / emissions.
F31	20A	Yellow	Auxiliary power socket - rear.
F32	20A	Yellow	Cigar lighter.
F33	20A	Yellow	HEGO / emissions.
F34	20A	Yellow	HEGO / emissions.
F35	5A	Tan	Air conditioning compressor clutch.
F36	15A	Blue	Engine management system 5 (V6 diesel only).
F37	15A	Blue	Ignition coils.
F38	5A	Tan	Power steering.
F39	5A	Tan	Headlamp levelling system.
F40	15A	Blue	Water pump (supercharged vehicles only).
F41	5A 10A 20A	Tan Red Yellow	Engine management system 1 (V6 diesel only). Engine management system 1 (petrol). Engine management system 1 (diesel only).
F42	10A 20A 30A	Red Yellow Green	Engine management system 2 (V8 petrol only). Engine management system 2 (I4 diesel only). Engine management system 2 (V6 petrol and V6 diesel only).
F43	5A 10A	Tan Red	Engine management system 3 (diesel only). Engine management system 3 (petrol only).
F44	5A 10A 15A	Tan Red Blue	Engine management system 4 (V6 diesel only). Engine management system 4 (I4 diesel only). Engine management system 4 (V8 petrol only).
F45	100A	Violet	Radiator cooling fan (diesel and V8 petrol only).