## Portable media

## CONNECTING MULTIPLE DEVICES

0

Do not plug non-audio devices into the USB port.

You can connect multiple devices simultaneously to the portable media interface and switch between them using the touch screen. Select iPod, USB, Bluetooth® or AUX, to switch between modes.

The device docked first will remain the active device until you choose to change.

If, after changing to the newly-docked device, you change back to the first device, play will resume at the point you left it (USB and iPod only).

**Note:** You cannot use a USB hub to connect more than one USB device to the audio unit.

**Note:** Devices connected to the iPod and USB ports will be charged, but devices that are fully discharged will not play.

**Note:** Options such as **Repeat** and **Shuffle** relate to the device currently playing, they will not apply to any subsequent device.

## PAIRING AND CONNECTING USING THE MEDIA PLAYER

For further information on **Bluetooth**® wireless technology, see **127**, **BLUETOOTH® INFORMATION**.

**Note:** The process of pairing and connecting your media device with the vehicle, using the media device, will vary depending on the type of media device.

- 1. Switch on the ignition and make sure the touch screen is active.
- 2. From the **Home** menu, select **Audio/Video** and then **My music**.
- 3. A menu will appear. Select Search new.
- 4. Select the Device to vehicle option.

**Note:** The vehicle's **Bluetooth**® wireless technology system is only discoverable for 3 minutes.

- 5. Using the media device, search for Bluetooth® wireless technology devices. On some media devices, this is referred to as new paired device. See your media device's operating instructions for further information.
- 6. When the vehicle's Bluetooth® wireless technology system is discovered, follow the on-screen instructions. Select Yes when prompted, to confirm the pairing. Either your device or the vehicle system will ask for a PIN (Personal Identification Number). When prompted, enter a PIN of your choice and select OK to confirm.
- 7. Enter the same PIN into the other device.
- 8. Once your device is paired and connected to the system, a confirmation message will be displayed, before switching to the My music, Bluetooth® wireless technology screen.

**Note:** Some media devices do not automatically connect and need to be manually connected, via the device or by using the **Change device** option.

## PAIRING AND CONNECTING USING THE TOUCH SCREEN

- Switch on your Bluetooth® wireless technology device's connection. Make sure that it is in Bluetooth® wireless technology discoverable mode, sometimes referred to as find me mode (see your device's operating instructions for more information).
- 2. Switch on the ignition and make sure the touch screen is active.
- From the Home menu, select Audio/Video and then My Music.